



Cisco 7600 Series Router Supervisor Engine and Route Switch Processor Guide

January 2008

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-10100-04

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

Modifying the equipment without Cisco's written authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCVP, the Cisco logo, and the Cisco Square Bridge logo are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networking Academy, Network Registrar, *Packet*, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco 7600 Series Router Supervisor Engine and Route Switch Processor Guide
Copyright © 2007-2008 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface vii

Contents vii

Document History vii

Document Organization viii

Document Conventions viii

 Warning Definition ix

Related Documentation ix

Obtaining Documentation, Obtaining Support, and Security Guidelines x

CHAPTER 1

Cisco 7600 Product Overview 1-1

Cisco 7600 Series Routers 1-1

 Supported Hardware 1-2

 Features 1-3

Port Addresses 1-5

 Physical Interface Addresses 1-5

 MAC Addresses 1-6

CHAPTER 2

Route Switch Processors and Supervisor Engines 2-1

Overview 2-2

Route Switch Processor 720 2-6

 RSP720 Features 2-7

 Supported Chassis, Line Cards, and Modules 2-7

 Unsupported Hardware and Features 2-7

RSP720 with 10GE Uplink Ports 2-8

 RSP720-10GE Features 2-8

 Supported Chassis, Line Cards, and Modules 2-9

 RSP720-10GE Usage Guidelines and Limitations 2-10

 QoS on the RSP720-10GE 2-10

Supervisor Engine 720 and Supervisor Engine 32 2-12

 Front-Panel Controls (RSP720, RSP720-10GE, Sup720, Sup32) 2-12

 Front-Panel LEDs (RSP720, RSP720-10GE, Sup720, Sup32) 2-13

Supervisor Engine 2 2-14

CHAPTER 3

Installing and Configuring Route Switch Processors and Supervisor Engines 3-1

- Preparing for Installation or Removal 3-1
 - Safety Precautions for Module Installation and Removal 3-2
 - Preventing Electrostatic Discharge Damage 3-2
 - Tools Required for Module Installation 3-3
- Determining Module Location 3-3
- Installing a Supervisor Engine or Route Switch Processor 3-4
- Removing a Supervisor Engine or Route Switch Processor 3-7
- Hot Swapping (OIR) Modules 3-8
- Removing and Replacing Memory 3-8
- Connecting to the Console Port 3-9
 - Connecting a Terminal 3-9
 - Connecting a Modem 3-10
- Connecting to the Uplink Ports 3-10
- Using Flash Memory Cards 3-12
 - Installing a Flash Memory Card 3-13
 - Removing a Flash Memory Card 3-14
- Power Management and Environmental Monitoring 3-14
- Determining Software Feature Support 3-14
- Configuring a Supervisor Engine or Route Switch Processor 3-14

APPENDIX A

Technical Specifications A-1

- Module Specifications A-1
- Regulatory Standards Compliance A-1

APPENDIX B

Cable and Connector Specifications B-1

- Limiting Connection Distances B-1
- Uplink Port Transceiver Modules B-2
 - 1GE Uplink Ports and Cabling Specifications B-3
 - 10GE Uplink Ports and Cabling Specifications B-5
 - GBIC Module Cabling Specifications B-6
- Console Port Cabling Specifications and Pinouts B-6
 - Console Port Cabling Specifications B-6
 - Console Port Signals and Pinouts B-7

Identifying a Rollover Cable	B-7
DB-9 Adapter (for Connecting to a PC)	B-8
DB-25 Adapter (for Connecting to a Terminal)	B-9
Modem Adapter	B-9
Console Port Mode 2 Signaling and Pinouts (Sup2 Only)	B-10
RJ-45 Connector	B-10
Fiber-Optic Connectors	B-12
SC Connectors	B-12
MT-RJ Connectors	B-13
LC Connectors	B-14
Cleaning the Fiber-Optic Connectors	B-15
LX/LH GBIC and MMF Cable Considerations	B-16
Patch Cord	B-16
Patch Cord Configuration Example	B-16
Patch Cord Installation	B-17

INDEX



Preface

This guide describes the route switch processors and supervisor engines supported by Cisco 7600 series routers. It also provides technical specifications for these modules and describes cable and connector specifications.



Caution

Only trained and qualified service personnel (as defined in IEC 60950 and AS/NZS3260) should install, replace, or service the equipment described in this document.

Contents

This preface contains the following sections:

- [Document History, page vii](#)
- [Document Organization, page viii](#)
- [Document Conventions, page viii](#)
- [Related Documentation, page ix](#)
- [Obtaining Documentation, Obtaining Support, and Security Guidelines, page x](#)

Document History

[Table 1](#) lists the technical changes made to this document since it was first printed.

Table 1 Document History

Revision	Date	Change Summary
OL-10100-04	January 2008	Added information about the Route Switch Processor 720 with 10-GE uplink ports, introduced in Cisco IOS Release 12.2SRC.
OL-10100-03	May 2007	Removed eFSU from the list of unsupported features for the Route Switch Processor 720. Beginning in Cisco IOS Release 12.2SRB1, eFSU and ISSU are supported on the RSP720, Sup720, and Sup32. Added a note that Cisco IOS Release 12.2SXF is the last release in which the Supervisor Engine 720 (with PFC3A) is supported.

Table 1 *Document History (continued)*

Revision	Date	Change Summary
OL-10100-02	February 2007	Added information about the Route Switch Processor 720 (a new supervisor engine) introduced in Cisco IOS Release 12.2SRB.
OL-10100-01	May 2006	Initial release of the document.

Document Organization

This document is organized as follows:

Chapter	Title	Description
Chapter 1	Cisco 7600 Product Overview	Provides an overview of Cisco 7600 series routers, and interface and port addresses.
Chapter 2	Route Switch Processors and Supervisor Engines	Describes the route switch processors (RSPs) and supervisor engines supported on Cisco 7600 series routers.
Chapter 3	Installing and Configuring Route Switch Processors and Supervisor Engines	Provides instructions for installing and removing RSPs and supervisor engines and connecting to the console and uplink ports.
Appendix A	Technical Specifications	Lists the technical specifications for the RSP and supervisor engines.
Appendix B	Cable and Connector Specifications	Lists the cable and connector specifications for the RSPs and supervisor engines.

Document Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands, command options, and keywords are in boldface .
<i>italic</i> font	Command arguments for which you supply values are in <i>italics</i> .



Caution

Means *reader be careful*. You are capable of doing something that might result in equipment damage or loss of data.



Note

Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this document.

Warning Definition



IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. Statement 1071

SAVE THESE INSTRUCTIONS

See *Regulatory Compliance and Safety Information for the Cisco 7600 Series Routers* for translations of warnings and information about the compliance and safety standards with which Cisco 7600 series routers conform.

Related Documentation

The following documents provide additional information about Cisco 7600 series routers:

- *Cisco 7600 Series Routers Documentation Roadmap*
- *Supported Hardware for Cisco 7600 Series Routers*
- *Regulatory Compliance and Safety Information for the Cisco 7600 Series Routers*
- *Cisco 7600 Series Router Installation Guide*
- *Cisco 7609 Router Installation Guide (OSR-7609)*
- *Cisco 7600 Series Router Module Installation Guide*
- *Cisco 7600 Series Router Cisco IOS Command Reference*
- *Cisco 7600 Series Router Cisco IOS System Message Guide*
- *Cisco 7600 Series Router Cisco IOS Software Configuration Guide*

Documentation for the Cisco 7600 series router is available online at the following URL:

http://www.cisco.com/en/US/products/hw/routers/ps368/tsd_products_support_series_home.html

For information about MIBs, refer to this URL:

<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>



CHAPTER 1

Cisco 7600 Product Overview

This chapter provides an overview of the Cisco 7600 series routers and describes interface and port addresses on the routers. It contains the following sections:

- [Cisco 7600 Series Routers, page 1-1](#)
- [Port Addresses, page 1-5](#)



Note

This document does not contain instructions for installing the router. For instructions on how to install the router, see the *Cisco 7600 Series Router Installation Guide*.

Cisco 7600 Series Routers

The Cisco 7600 series routers consist of these routers:

- Cisco 7603 router (3 slots)
- Cisco 7604 router (4 slots)
- Cisco 7606 router (6 slots)
- Cisco 7609 router (9 vertical slots)
- Cisco 7613 router (13 slots)



Note

In addition, Cisco IOS Release 12.2SRB and later releases introduced enhanced versions of the 3-slot, 6-slot, and 9-slot chassis (CISCO7603-S, CISCO7606-S, and CISCO7609-S). These enhanced chassis provide increased power and cooling capabilities and an enhanced switch fabric to support high-power processors and future line cards, which will provide 80-Gbps connections.

Cisco 7600 series routers provide optical wide area network (WAN) and metropolitan-area network (MAN) networking with a focus on line-rate delivery of high-touch IP services at the edge of service provider networks.

Supported Hardware

Cisco 7600 series routers support the following hardware:

- A supervisor engine (such as the Sup720, Sup32, or Sup2) or Route Switch Processor (RSP720) with modular Gigabit Ethernet uplink ports. Each supervisor engine or RSP has two integrated daughter cards: a policy feature card (PFC) and a multilayer switch feature card (MSFC). See the [“Overview” section on page 2-2](#) for details.

**Note**

You can install a redundant supervisor engine or RSP in the router to provide a backup in case the active module fails. Both supervisor engines or RSPs must be identical. If the system does not include a redundant supervisor engine or RSP, you can install another type of module (for example, FlexWAN, OSM, or SIP and SPA) in the slot that is reserved for the redundant processor card.

- Optical Services Modules (OSMs), FlexWAN and Enhanced FlexWAN modules, recommended Catalyst 6000 family modules, and SPA interface processors (SIPs) in any combination.
 - Two additional modules for the Cisco 7603 router
 - Three additional modules for the Cisco 7604 router
 - Five additional modules for the Cisco 7606 router
 - Eight additional modules for the Cisco 7609 router
 - Twelve additional modules for the Cisco 7613 router

**Note**

Specific combinations of supervisor engines or RSPs and modules may not be supported in your chassis. See the *Supported Hardware for Cisco 7600 Series Routers* guide for information about which combinations are not supported.

- Hot-swappable fan assembly
- Redundant AC-input or DC-input power supplies
- Redundant AC-input or DC-input power entry modules (PEMs) (Cisco 7603 and Cisco 7606 routers only)
- An optional Switch Fabric Module (WS-X6500-SFM2) that is available with the Supervisor Engine 2. For redundancy, you can install a redundant SFM2 module. The module that is installed first functions as the primary module.

Features

Table 1-1 lists some key features of the Cisco 7600 series routers.

Table 1-1 Cisco 7600 Series Routers Key Features

Feature	Description
Performance and configuration	For detailed information about the features supported on Cisco 7600 series routers, see the <i>Cisco 7600 Series Router Cisco IOS Software Configuration Guide</i> for the version of software being used on the router.
Supervisor engine or route switch processor	<ul style="list-style-type: none"> Modular, upgradable feature modules for core switching logic Modular Gigabit Ethernet ports that you can configure with Gigabit Interface Converter (GBIC), small form-factor pluggable (SFP), XENPAK, and X2 optics modules Several combinations of multilayer switch feature cards (MSFCs) and policy feature cards (PFCs) supported (see Table 2-1): <ul style="list-style-type: none"> MSFC4 and PFC3C or PFC3CXL (for the RSP720, see note below) MSFC3 and PFC3B, PFC3BXL, or PFC3A (see note below) MSFC2 and PFC or PFC2 The MSFC contains the switch processor and route processor (SP/RP) for the router. PCMCIA slot Console port for terminal and modem access <p>Note The Route Switch Processor 720 (RSP720) is the newest supervisor engine for the Cisco 7600 series routers. It is available in Cisco IOS Release 12.2SRB and later releases.</p> <p>Note Cisco IOS Release 12.2SRC introduces support for the RSP720-10GE (an RSP with 10 Gigabit Ethernet uplink ports).</p> <p>Note Cisco IOS Release 12.2SXF is the last release in which the PFC3A is supported. Later releases do not support this PFC.</p>
Fault tolerance and redundancy	<ul style="list-style-type: none"> Support for two hot-swappable (redundant) supervisor engines or route switch processors, including fast switchover to the redundant (standby) module Support for two redundant AC- or DC-input, load-sharing power supplies Support for two redundant AC- or DC-input PEMs (Cisco 7603 and Cisco 7606 routers only) Power management for modules and power supplies Environmental monitoring of critical system components Hot-swappable fan assembly Redundant clock modules LACP 1-1 redundancy with fast switchover

Table 1-1 Cisco 7600 Series Routers Key Features (continued)

Feature	Description
Memory components	<ul style="list-style-type: none"> Electrically erasable programmable read-only memory (EEPROM) on the supervisor engine or route switch processor stores module-specific information, such as the serial number, part number, controller type, hardware revision, configuration information, and other details unique to each module. NVRAM for storing configuration information. DRAM for default system software. Internal flash memory—To store the boot image. The defaults are: <ul style="list-style-type: none"> The RSP720 SP/RP and the Sup32 SP contain a CompactFlash (CF) adapter that provides 512 MB of internal flash memory. The Sup720 SP/RP, Sup32 RP, and Sup2 SP/RP contain 32-MB or 64-MB of internal flash memory. Cisco IOS Release 12.2(18)SXF and later releases support the CF adapter as an orderable option (Cisco part number CF-ADAPTER=) for these Sups.¹ <p>Note In the command-line-interface (CLI), you access internal flash memory as bootdisk (CF adapter) or bootflash (non-CF adapter). When you install a CF adapter on the Sup720, Sup32, or Sup2, bootflash becomes an alias to bootdisk.</p> <ul style="list-style-type: none"> External flash memory—To store and run software images and configuration files or to serve as an input/output (I/O) device. You can install 64-MB, 128-MB, 256-MB, or 512-MB flash memory cards, or 1-GB MicroDrive card, in slots on the supervisor engine or RSP front panel. <p>The Sup2 supports PCMCIA flash memory cards only. It does not support CompactFlash or MicroDrive cards.</p> <ul style="list-style-type: none"> Flash file system—Flash memory contains a file system. You can use a variety of commands to manage the file system (such as cd, pwd, dir, and delete). The file system includes the following devices: <ul style="list-style-type: none"> Onboard bootflash/bootdisk Flash memory slot
Component hot swapping	All components (including optional redundant modules and fans) support hot swapping, which allows you to add, replace, or remove components without interrupting the system power or causing other software or interfaces to shut down.
Management	<ul style="list-style-type: none"> CLI through the console port or Telnet Simple Network Management Protocol (SNMP)

1. For information on how to install a CF adapter, see the instructions at:
http://www.cisco.com/en/US/products/hw/switches/ps708/products_installation_and_configuration_guide09186a0080537ae3.html

Port Addresses


Each port (or interface) in the Cisco 7600 series router has several different types of addresses. The physical interface address is the actual physical location (slot and port) of the interface connector within the chassis. The system software uses the physical addresses to control activity within the router and to display status information. These physical slot and port addresses are not used by other devices in the network; they are specific to the individual router and its internal components and software. For more information, see the [“Physical Interface Addresses” section on page 1-5](#).

The Media Access Control (MAC) address is a standardized data link layer address that is required for every port or device that connects to a network. Other devices in the network use MAC addresses to locate specific ports in the network and to create and update routing tables and data structures. Routers use a unique method, described in the [“MAC Addresses” section on page 1-6](#), to assign and control the MAC addresses of their interfaces.

Physical Interface Addresses

Physical port addresses specify the actual physical location of each port on every module in the router, as shown in [Figure 1-1](#). The port address is a two-part number in the format *slot/port number* (for example, 1/1, 1/2, 2/1, 2/2, and so on):

- *Slot*—Identifies the slot in which the module is installed. Depending on the router layout, the slots are numbered from top to bottom or right to left starting with 1 (1/*n*, 2/*n*, and so on).
 - On horizontal-oriented chassis (such as the Cisco 7606 and Cisco 7613 routers), slots are numbered from top to bottom.
 - On vertical-oriented chassis (such as the Cisco 7609 router), slots are numbered from right to left.
- *Port number*—Identifies the physical port number on the module. Port numbers always begin at 1 (*n*/1, *n*/2, and so on).
 - On horizontal-oriented modules, ports are numbered from left to right.
 - On vertical-oriented modules, ports are numbered from top to bottom.

Figure 1-1 Cisco 7609 Router Port Address Examples

The supervisor engine and route switch processor have two or more uplink ports (numbered $n/1$, $n/2$, and so on). The Supervisor Engine 32 (WS-SUP32-GE-3B) has nine uplink ports, numbered $n/1$ to $n/9$.

In some cases, a single port supports two different types of connectors (for example, Port 2 on the Supervisor Engine 720 supports a Gigabit Ethernet SFP module or a 10/100/1000-Mbps RJ-45 connector). However, only one of the two options can be active at a time.

MAC Addresses

All network interface connections (ports) require a unique MAC address. The MAC address of an interface is stored in electrically erasable programmable read-only memory (EEPROM) on a component that resides directly on the interface circuitry. The router system code reads the EEPROM for each interface in the system, learns the MAC addresses, and then initializes appropriate hardware and data structures. Each VLAN in the spanning tree has one unique MAC address. This addressing scheme enables the router to identify the state (connected or not connected) of each interface. When you hot swap a module, the MAC address changes with the module.



CHAPTER 2

Route Switch Processors and Supervisor Engines

This chapter describes the route switch processors and supervisor engines supported on Cisco 7600 series routers and provides instructions for performing basic tasks on the modules. It contains the following sections:

- [Overview, page 2-2](#)
- [Route Switch Processor 720, page 2-6](#)
- [RSP720 with 10GE Uplink Ports, page 2-8](#)
- [Supervisor Engine 720 and Supervisor Engine 32, page 2-12](#)
- [Supervisor Engine 2, page 2-14](#)



Note

The route switch processor is the newest version of supervisor engine. See [Table 2-1](#) for a list of the route switch processor and supervisor engine configurations supported on Cisco 7600 series routers. Be sure to review the release notes for the software version running on your router for information about any restrictions and limitations that might apply.

Overview

The supervisor engine or route switch processor (RSP) is a module that is installed in one of the card slots in the router. The supervisor engine or RSP provides switching and local and remote management for the router and also contains the uplink ports for the router. Both types of modules (supervisor engine and RSP) perform the same functions in the router.

Cisco 7600 series routers support the following types of RSPs and supervisor engines:

- Route Switch Processor 720—Supported on all chassis (including enhanced) except the Cisco 7603 router and the Cisco OSR-7609. Available in Cisco IOS Release 12.2SRB and later releases.
- RSP720-10GE (with 10GE uplink ports)—Supported on the Cisco 7604 and 7609 routers and the Cisco 7603-S, 7606-S, and 7609-S routers (enhanced chassis). Available in Cisco IOS Release 12.2SRC and later releases.
- Supervisor Engine 720—Supported on all Cisco 7600 series routers.
- Supervisor Engine 32—Supported on all but the Cisco 7603 router.
- Supervisor Engine 2—Supported on all but the Cisco 7613 router. The Supervisor Engine 2 is no longer supported in Cisco IOS Release 12.2SRA and later releases.

Although the router can operate with a single supervisor engine or RSP, you can also install a second redundant module (of the same type) in the chassis. Only one module is active at a time. The second module acts as a “standby,” serving as a backup if the active module fails.



Note

If the system does not include a redundant supervisor engine or RSP, you can install another type of module in the slot reserved for the redundant supervisor engine or RSP.

The supervisor engine or RSP contains the following integrated daughter cards that perform forwarding and routing and provide the protocols supported on the router. Several configurations of daughter cards are supported (as shown in [Table 2-1](#)).

- Policy Feature Card (PFC) is the forwarding plane and does the following:
 - Performs Layer 2 and Layer 3 forwarding.
 - Enforces access control list (ACL) functions.
 - Performs policing and marking for quality of service (QoS) traffic.
 - Collects Netflow statistics.



Note

A high-capacity (XL) PFC is also available. The XL version (PFC3BXL or PFC3CXL) provides more memory for more routing table and netflow cache capacity than a PFC. It allows routing and forwarding processes to be offloaded from the supervisor engine or RSP to the PFC, thus increasing the performance of the supervisor engine or RSP.

- Multilayer Switch Feature Card (MSFC) is the control plane and does the following:
 - Performs routing for the chassis. The MSFC contains the route processor (RP) and switch processor (SP) for the router.
 - Runs Layer 2 and Layer 3 protocols, such as the Spanning Tree Protocol (STP) and others. For information about supported protocols, see the *Cisco 7600 Series Router Cisco IOS Software Configuration Guide* and the release notes for the software version running on the router.

Table 2-1 lists the RSP and supervisor engine configurations supported on Cisco 7600 series routers. Specific combinations of processors and modules may not be supported in your chassis. See the release notes for your software version for information about supported combinations.

Table 2-1 Route Switch Processor and Supervisor Engine Configurations

Product Number	Description
Route Switch Processor 720	
RSP720-3C-10GE	<ul style="list-style-type: none"> Two 10 Gigabit Ethernet (10GE) uplink ports support 10-Gbps X2 modules Three Gigabit Ethernet (1GE) uplink ports: two ports support 1-Gbps small form-factor pluggable (SFP) module; one port supports 10/100/1000-Mbps RJ-45 connector <p>Note Use Category 5 Shielded Twisted Pair cable at the port that supports the 10/100/1000-Mbps RJ-45 connector.</p> <ul style="list-style-type: none"> Integrated 720-Gbps switch fabric PFC3C and MSFC4 with 512-MB bootflash, 4-MB NVRAM, 4-MB ROMmon, and several DRAM options: <ul style="list-style-type: none"> Route processor (RP): 1- to 4-GB DRAM (default 1 GB) Switch processor (SP): 1- to 2-GB DRAM (default 1 GB) One CompactFlash Type II slot (512 KB) on front panel and two internal CompactFlash (512 KB each for RP and SP; you can optionally increase each internal CompactFlash to 1 GB) Requires larger power supplies and a high-speed fan tray QoS port architecture, 10GE ports (Rx/Tx): 8q8t/1p7q8t (CoS) QoS port architecture, 1GE ports (Rx/Tx): 2q8t/1p3q8t
RSP720-3CXL-10GE	<ul style="list-style-type: none"> Two 10GE) uplink ports support 10-Gbps X2 modules Three 1GE)uplink ports: two ports support 1-Gbps small form-factor pluggable (SFP) module; one port supports 10/100/1000-Mbps RJ-45 connector <p>Note Use Category 5 Shielded Twisted Pair cable at the port that supports the 10/100/1000-Mbps RJ-45 connector.</p> <ul style="list-style-type: none"> Integrated 720-Gbps switch fabric PFC3CXL (high-capacity) and MSFC4 with 512-MB bootflash, 4-MB NVRAM, 4-MB ROMmon, and several DRAM options: <ul style="list-style-type: none"> Route processor (RP): 1- to 4-GB DRAM (default 2 GB) Switch processor (SP): 1- to 2-GB DRAM (default 1 GB) One CompactFlash Type II slot (512 KB) on front panel and two internal CompactFlash (512 KB each for RP and SP; you can optionally increase each internal CompactFlash to 1 GB) Requires larger power supplies and a high-speed fan tray QoS port architecture, 10GE ports (Rx/Tx): 8q8t/1p7q8t (CoS) QoS port architecture, 1GE ports (Rx/Tx): 2q8t/1p3q8t

Table 2-1 *Route Switch Processor and Supervisor Engine Configurations (continued)*

Product Number	Description
Note	See the “ QoS on the RSP720-10GE ” section on page 2-10 for more information about the QoS port architecture on the uplink ports.
RSP720-3C-GE	<ul style="list-style-type: none"> Two Gigabit Ethernet uplink ports: port 1 supports a 1-Gbps SFP module; port 2 is configurable with either a 1-Gbps SFP module or a 10/100/1000-Mbps RJ-45 connector Integrated 720-Gbps switch fabric PFC3C and MSFC4 with 512-MB bootflash, 4-MB NVRAM, 4-MB ROMmon, and several DRAM options: <ul style="list-style-type: none"> RP: 1- to 4-GB DRAM (default 1 GB) SP: 1- to 2-GB DRAM (default 1 GB) Two CompactFlash Type II slots on front panel (512 KB default) and two internal CompactFlash slots (one each for RP and SP, 512 KB default for each) Requires larger power supplies and a high-speed fan tray QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
RSP720-3CXL-GE	<ul style="list-style-type: none"> Two Gigabit Ethernet uplink ports: port 1 supports a 1-Gbps SFP module; port 2 is configurable with either a 1-Gbps SFP module or a 10/100/1000-Mbps RJ-45 connector Integrated 720-Gbps switch fabric PFC3CXL (high-capacity) and MSFC4 with 512-MB bootflash, 4-MB NVRAM, 4-MB ROMmon, and several DRAM options: <ul style="list-style-type: none"> Route processor (RP): 1- to 4-GB DRAM (default 2 GB) Switch processor (SP): 1- to 2-GB DRAM (default 1 GB) Two CompactFlash Type II slots on front panel (512 KB default) and two internal CompactFlash slots (one each for RP and SP, 512 KB default for each) Requires larger power supplies and a high-speed fan tray QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
Supervisor Engine 720	
WS-SUP720	<ul style="list-style-type: none"> Two Gigabit Ethernet uplink ports: port 1 supports a 1-Gbps SFP module; port 2 is configurable with either a 1-Gbps SFP module or a 10/100/1000-Mbps RJ-45 connector Integrated 720-Gbps switch fabric PFC3A and MSFC3 with 2-MB NVRAM, 512-MB DRAM, and 64-MB bootflash (see note below) Two CompactFlash Type II slots Requires larger power supplies and a high-speed fan tray QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
Note	Cisco IOS Release 12.2SXF is the last release in which the Sup720 with PFC3A is supported.

Table 2-1 **Route Switch Processor and Supervisor Engine Configurations (continued)**

Product Number	Description
WS-SUP720-3B	<ul style="list-style-type: none"> Two Gigabit Ethernet uplink ports: port 1 supports a 1-Gbps SFP module; port 2 is configurable with either a 1-Gbps SFP module or a 10/100/1000-Mbps RJ-45 connector Integrated 720-Gbps switch fabric PFC3B and MSFC3 with 2-MB NVRAM, 512-MB DRAM, and 64-MB bootflash (see note below) Two CompactFlash Type II slots Requires larger power supplies and a high-speed fan tray QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
WS-SUP720-3BXL	<ul style="list-style-type: none"> Two Ethernet uplink ports: port 1 supports a 1-Gbps SFP module; port 2 is configurable with either a 1-Gbps SFP module or a 10/100/1000-Mbps RJ-45 connector Integrated 720-Gbps switch fabric PFC3BXL and MSFC3 with 2-MB NVRAM, 1-GB DRAM, and 64-MB bootflash; high-capacity PFC3BXL allows routing and forwarding processes to be offloaded from the supervisor engine to the PFC (see note below) Two CompactFlash Type II slots Requires larger power supplies and a high-speed fan tray QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
Note	A CompactFlash (CF) adapter with 512-MB bootflash is available for Sup720 modules in Release 12.2(18)SXF and later releases. Use the Cisco part number CF-ADAPTER= for ordering.
Supervisor Engine 32	
WS-SUP32-GE-3B	<ul style="list-style-type: none"> Nine Gigabit Ethernet uplink ports: eight SFP modules and one RJ-45 10/100/1000-Mbps connector Integrated 32-Gbps switch fabric PFC3B and MSFC2 daughter cards (see notes below) QoS port architecture (Rx/Tx): 1p3q8t/1p3q8t
WS-SUP32-10GE-3B	<ul style="list-style-type: none"> Two 10-Gigabit Ethernet ports (XENPAKs) and one 10/100/1000-Mbps connector Integrated 32-Gbps switch fabric PFC3B and MSFC2 daughter cards (see notes below) QoS port architecture (Rx/Tx): 1p3q8t/1p3q8t
Note	To run Release 12.2SRB, the Sup32 requires a minimum of 512-MB DRAM.
Note	A CF adapter with 512-MB bootflash is available for Sup32 modules in Release 12.2(18)SXF and later releases. Use the Cisco part number CF-ADAPTER= for ordering.
Supervisor Engine 2	

Table 2-1 *Route Switch Processor and Supervisor Engine Configurations (continued)*

Product Number	Description
WS-X6K-S2-MSFC2	<ul style="list-style-type: none"> Two dual-port 1000BASE-X GBIC uplinks, 16-MB bootflash, 128-MB DRAM on supervisor engine and 128 MB on MSFC2 PFC2 and MSFC2 Fabric enabled to support optional switch fabric module (SFM2) QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
WS-X6K-S2U-MSFC2	<ul style="list-style-type: none"> Two dual-port 1000BASE-X GBIC uplinks, 32-MB bootflash, 256-MB DRAM on supervisor engine and 256 MB on MSFC2 PFC2 and MSFC2 Fabric enabled to support optional SFM2 QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
WS-X6K-S2-PFC2	<ul style="list-style-type: none"> Two dual-port 1000BASE-X GBIC uplinks PFC2; fabric enabled, supports optional SFM2 QoS port architecture (Rx/Tx): 1p1q4t/1p2q2t
WS-X6500-SFM2	<ul style="list-style-type: none"> (Optional) SFM2
Note The Sup2 is not supported in Cisco IOS Release 12.2SRA and later releases.	

Route Switch Processor 720


This section describes the Route Switch Processor 720 (RSP720). The Cisco 7600 RSP720 consists of a full-size board and two integrated daughter cards: the MSFC4 and a PFC3C or PFC3CXL. The RSP720 has an integrated switch fabric that interconnects all of the line cards in the Cisco 7600 router with point-to-point 20-Gbps full-duplex serial channels.



Note

- Cisco IOS Release 12.2SRB and later releases support the RSP720; earlier releases do not. The RSP720 is supported on all Cisco 7600 routers (including enhanced chassis) except the Cisco 7603 and the Cisco OSR-7609.
- Cisco IOS Release 12.2SRC and later releases support an RSP720 that has 10GE uplinks (RSP720-3C-10GE and RSP720-3CXL-10GE). See the [“RSP720 with 10GE Uplink Ports” section on page 2-8](#) for more information.

[Figure 2-1](#) shows the RSP720-3C-GE front panel, which is the same as the RSP720-3CXL-GE front panel. See [Table 2-2](#) and [Table 2-3](#) for information about the front-panel controls and LEDs.

Figure 2-1 Route Switch Processor 720 (RSP720-3C-GE) Front Panel

RSP720 Features

The RSP720 provides several new features and enhancements, which are summarized here. For details, see the *Cisco 7600 Series Router Cisco IOS Software Configuration Guide, Release 12.2SR*.

- 720 gigabits per second (Gbps) bandwidth (320 Gbps ingress and 320 Gbps egress)
- A faster CPU and additional memory to support larger configurations and more subscribers
- Performance and scalability improvements
- Quality of service (QoS) enhancements

Supported Chassis, Line Cards, and Modules

The RSP720 supports the following Cisco 7600 chassis, line cards and modules:

- Supported on all Cisco 7600 routers (including enhanced chassis) except the Cisco 7603 and the Cisco OSR-7609
- SPA interface processors (SIPs) and their shared port adapters (SPAs): 7600-SIP-600, 7600-SIP-400, and 7600-SIP-200
- Enhanced FlexWAN module (WS-X6582-2PA)
- Ethernet services modules: 2-port 10 GE line card (7600-ESM-2X10GE) and 20-port 1 GE line card (7600-ESM-20X1GE)
- Distributed Forwarding Cards: DFC3C, DFC3CXL, DFC3B, DFC3BXL
- LAN cards (which require DFC): WS-X6704-10GE, WS-X6724-SFP, WS-X6748-SFP, WS-X6748-GE-TX, WS-X6708A-10GE, WS-X67xxA series, WS-X6148-FE-SFP, WS-X6148A-GE-TX

Unsupported Hardware and Features

The following hardware and features are not supported by the RSP720:

- Unsupported chassis: Cisco 7603, Cisco OSR-7609.
- Unsupported modules: Services modules, Optical Service Modules (OSMs), FlexWAN module.
- Server load balancing (SLB) is not supported, although it is supported on the Supervisor Engine 720.

RSP720 with 10GE Uplink Ports

Cisco IOS Release 12.2SRC introduces a new RSP720 with 10 Gigabit Ethernet (GE) uplink ports (RSP720-10GE). The Cisco 7600 RSP720-10GE consists of a full-size board and two integrated daughter cards: an MSFC4 and a PFC. The RSP720-10GE has an integrated switch fabric that interconnects all of the line cards in the router with point-to-point 20-Gbps full-duplex serial channels.

Two versions of the RSP720-10GE module are available:

- RSP720-3C-10GE
- RSP720-3CXL-10GE


Because of physical differences between the RSP720 and RSP720-10GE (such as the CPU memory map and ASIC operation), there are several configuration guidelines and restrictions you should be aware of. See the [“RSP720-10GE Usage Guidelines and Limitations”](#) section on page 2-10 for details.

Following are the total power requirements for the RSP720-10GE:

- RSP720-3C-10GE = 355 watts (total power)
- RSP720-3CXL-10GE = 378 watts (total power)

Figure 2-2 shows the RSP720-3C-10GE front panel. The RSP720-3CXL-10GE front panel is similar. See Table 2-2 and Table 2-3 for information about the front-panel controls and LEDs.

Figure 2-2 RSP720-3C-10GE Front Panel



Note

Use Category 5 Shielded Twisted Pair cable at the port that supports the 10/100/1000-Mbps RJ-45 connector.

RSP720-10GE Features

The RSP720-10GE provides all of the features of the RSP720 and also provides the following benefits:

- The RSP720-10GE has two 10GE uplink ports and three 1GE uplink ports. You can use the 10GE ports as high-bandwidth uplinks and save chassis slots for high-density interfaces, such as a SIP/SPA. This is especially useful in smaller chassis and in redundant configurations. For the three 1GE uplink ports, two ports support 1-Gbps SFP modules and one port supports a 10/100/1000-Mbps RJ-45 connector.



Note

Use CAT5 Shielded Twisted Pair cable at the port that supports the 10/100/1000-Mbps RJ-45 connector.

- The RSP720-10GE supports the following line rates for uplink traffic and backplane forwarding:

- 10 gigabits per second (Gbps) on both 10GE ports
- 1 Gbps on all three 1GE ports
- 16 Gbps backplane forwarding

When all five uplink ports are operational, the total bandwidth for uplink traffic is 20 Gbps (20 GE).

- The RSP720-10GE provides flexible memory options like the RSP720. The RSP720-10GE ships with 2-GB memory on the route processor (RP) and 1-GB memory on the switch processor (SP). Memory options are available to upgrade to 4-GB memory on the RP and 2-GB memory on the SP.
- The RSP720-10GE supports Route Processor Redundancy (RPR) mode. However, uplink ports on the standby supervisor will be unusable.

See the [“RSP720-10GE Usage Guidelines and Limitations”](#) section on page 2-10 for information about things to consider when you use the RSP720-10GE.

Supported Chassis, Line Cards, and Modules

The RSP720-10GE supports the following chassis and modules:

- Supported on the Cisco 7604 and 7609 chassis and the Cisco 7603-S, 7606-S, and 7609-S chassis



Note If you insert an RSP720-10GE into an unsupported chassis, the RSP720-10GE drops to ROMmon and only the console is accessible.

- SPA interface processors (SIPs) and their shared port adapters (SPAs): 7600-SIP-600, 7600-SIP-400, and 7600-SIP-200
- Enhanced FlexWAN module (WS-X6582-2PA)
- Ethernet services modules: 2-port 10 GE line card (7600-ESM-2X10GE) and 20-port 1 GE line card (7600-ESM-20X1GE)
- Distributed Forwarding Cards: DFC3C, DFC3CXL, DFC3B, DFC3BXL
- LAN cards (which require CFC or DFC): WS-X6704-10GE, WS-X6724-SFP, WS-X6748-SFP, WS-X6748-GE-TX, WS-X6708A-10GE, WS-X67xxA series, WS-X6148-FE-SFP, WS-X6148A-GE-TX
- Uplink port transceiver modules: see [Appendix B, “Cable and Connector Specifications”](#)



Note The RSP720-10GE also supports two new 8-port 10GE line cards (WS-X6708-10G-3C and WS-X6708-10G-3CXL). The line cards, which provide 2-to-1 oversubscription, are available in Cisco IOS Release 12.2SRC and later.

Unsupported Chassis and Modules

The RSP720-10GE does not support the following chassis and modules:

- Unsupported chassis: Cisco 7603, 7606, and 7613 chassis
- Unsupported modules: Services modules, Optical Service Modules (OSMs), FlexWAN module

Unsupported Features

In Cisco IOS Release 12.2SRC, the RSP720-10GE does not support the following features, which are supported on the RSP720:

- High-availability features such as NonStop Forwarding with Stateful Switchover (NSF/SSO) and In-Service Software Upgrade (ISSU) are not supported. Only Route Processor Redundancy (RPR) mode is supported.
- The uplinks on the standby RSP720-10GE are not active. This restriction exists because the uplink ports must perform lookups on the active RSP, which is not possible in RPR mode.
- Intelligent Service Gateway is not supported.
- Device authentication to prevent counterfeiting
- Keystore controller for key authentication
- Virtual switch functionality

RSP720-10GE Usage Guidelines and Limitations

Observe the following guidelines when using the RSP720-10GE:

- The RSP720-10GE runs the same Cisco IOS software images as the RSP720. The following software image feature sets are available for the RSP720-10GE: `ipservices`, `ipservicesk9`, `advipservices`, `advipservicesk9`, and `adventerprisek9`.
- Line cards require new firmware to operate with the RSP720-10GE. If a line card does not have the correct firmware, an error message is displayed on boot-up and the line card is powered off.
- The RSP720-10GE uses new ROMMON software for both the SP and RP. Because the RSP720-10GE and RSP720 use a different IO memory map, the RSPs cannot share the same ROMMON software.
 - If you attempt to load RSP720 ROMMON software onto the RSP720-10GE, the RSP720-10GE does not power up and the ROMMON banner is not displayed.
 - If you load RSP720-10GE ROMMON software onto the RSP720, Cisco IOS software boots up but the software detects a mismatch and enters ROMMON mode.
- You can configure the RSP720-10GE to run QoS features on all uplink ports (10GE and 1GE) or on 10GE ports only. A new CLI command (**`mls qos supervisor 10g-only`**) is available to configure the module to run QoS features on 10GE ports only. QoS operates differently in each mode. See the [“QoS on the RSP720-10GE” section on page 2-10](#) for more information.

QoS on the RSP720-10GE

The RSP720-10GE has both 10GE and 1GE uplink ports. You can configure the RSP720-10GE to run QoS features on all uplink ports (mixed mode) or on 10GE ports only. The number of queues available for QoS depends on which mode is used:

- In mixed mode (10GE and 1GE ports), the default, only four queues are available for QoS.

The QoS port architecture for 1GE ports is (Rx/Tx): **2q8t/1p3q8t**.

- In 10GE only mode, eight queues are available for QoS. Use the **mls qos supervisor 10g-only** command to enable 10GE only mode.

The QoS port architecture for 10GE only mode is as follows (Rx/Tx):

- **8q8t/1p7q8t** (CoS)
- **16q8t/1p15q8t** (DSCP)
- **16q1t/1p15q1t** (VLAN)

QoS Configuration Guidelines

As you configure QoS on the RSP720-10GE, consider the following:

- When you switch between mixed-mode QoS and 10GE only mode, any existing QoS configuration on the uplinks is lost. You must reconfigure QoS.
- While transitioning between modes, service will be temporarily lost on the uplinks.
- You can manually shut down all three 1GE ports before issuing the **mls qos supervisor 10g-only** command to switch to 10GE only mode. If you do not shut down the ports first, the **mls qos supervisor 10g-only** command shuts down the ports.
- When you switch from 10GE10GE only to mixed-mode QoS, you must issue the **no shutdown** command on each of the three 1GE ports to resume QoS service on those ports.
- In 10GE only mode, the 1GE ports are visible but they remain in an administratively down state.

Configuring 10GE Only QoS

Cisco IOS Release 12.2SRC introduces a new command to enable QoS features on 10GE uplink ports only. By default, the router runs in *mixed mode*, which means that QoS is enabled on both the 10GE uplink ports and the 1GE uplink ports.

mls qos supervisor 10g-only

no mls qos supervisor 10g-only



Note

You can shut down all three 1GE uplink ports before entering the **mls qos supervisor 10g-only** command. If you do not shut down the ports first, the **mls qos supervisor 10g-only** command shuts down the ports.

Supervisor Engine 720 and Supervisor Engine 32

The following figures (Figure 2-3, Figure 2-4, and Figure 2-5) show the front panel on the Supervisor Engine 720 (Sup720) and Supervisor Engine 32 (Sup32). The tables that follow describe the controls and LEDs on the RSP720, Sup720, and Sup32. For information on the Supervisor Engine 2 controls and LEDs, see the “Supervisor Engine 2” section on page 2-14.

Figure 2-3 Supervisor Engine 720 (WS-SUP720) Front Panel




Figure 2-4 Supervisor Engine 32 (WS-SUP32-GE-3B) Front Panel





Figure 2-5 Supervisor Engine 32 (WS-SUP32-10GE-3B) Front Panel



Front-Panel Controls (RSP720, RSP720-10GE, Sup720, Sup32)

Table 2-2 describes the front-panel controls on the Route Switch Processor 720 and RSP720-10GE, the Supervisor Engine 720, and the Supervisor Engine 32.

Table 2-2 RSP720, RSP720-10GE, Sup720, and Sup32 Front-Panel Controls

Component	Description
Status LEDs	Indicate the status of various functions on the module (see Table 2-3).
Reset Button	Restarts the router. Use a ballpoint pen tip or other small, pointed object to access the Reset button. Not all modules have a Reset button.
CompactFlash Disk Slots	One or two slots for flash memory cards. Do not remove the card from the slot while the disk LED is on. See the “Using Flash Memory Cards” section on page 3-12 for information about working with flash memory.
Console Port	Provides access to the router. The port is an EIA/TIA-232 asynchronous, serial connection with hardware flow control and an RJ-45 connector. See the “Connecting to the Console Port” section on page 3-9 for instructions on connecting to the console port. On the RSP720, the console port allows you to access either the switch processor (SP) or the route processor (RP).
Uplink Ports	Used to connect the router to other network devices. The uplink ports are configurable with SFP, XENPAK, or X2 optics modules. See the “Connecting to the Uplink Ports” section on page 3-10 for more information.
USB Ports (Sup32 only)	Each USB port can function as a console port or security key.

Front-Panel LEDs (RSP720, RSP720-10GE, Sup720, Sup32)

LEDs on the front panel of the supervisor engine or route switch processor show the status of the processor and other components installed in the router. [Table 2-3](#) lists the LED functions on the Route Switch Processor 720 and RSP720-10GE, the Supervisor Engine 720, and the Supervisor Engine 32. See [Table 2-5](#) for a list of LED functions on the Supervisor Engine 2.

Table 2-3 RSP720, Sup720, and Sup32 LEDs

LED	Color	Description
STATUS	Green	All diagnostics pass; the module is operational (normal initialization sequence).
	Orange	The module is booting or running diagnostics (normal initialization sequence).
	Yellow	Minor hardware problems.
	Red	An overtemperature condition occurred. (A major threshold has been exceeded during environmental monitoring.)
SYSTEM ¹	Green	All chassis environmental monitors are reporting OK.
	Orange	The module is powering up or a minor hardware fault has occurred.
	Red	Major hardware problem. The temperature of the supervisor engine or RSP has exceeded the major temperature threshold.
	Blinking Red	Continuous backplane stall.

Table 2-3 *RSP720, Sup720, and Sup32 LEDs (continued)*

LED	Color	Description
ACTIVE	Green	The supervisor engine or RSP is operational and active.
	Orange	The supervisor engine or RSP is powering up or is in standby mode.
PWR MGMT¹	Green	Sufficient power is available for all modules installed in the router.
	Orange	The supervisor engine or RSP is powering up or has minor hardware problems.
	Red	Major hardware problem.
DISK	Green	The disk is active. Do not remove the disk while the light is on or the file may be corrupted.
LINK	Green	The port is operational.
	Orange	The port is disabled.
	Flashing orange	The port is bad.
	Off	The supervisor engine or RSP is powering up or the port is enabled and there is no link.

1. The SYSTEM and PWR MGMT LEDs on a redundant supervisor engine or RSP are synchronized to the active module.

Supervisor Engine 2

This section describes the Supervisor Engine 2 (see [Figure 2-6](#)), which has slightly different controls and features than the Supervisor Engine 720 and Supervisor Engine 32. [Table 2-4](#) describes the controls and features on the front panel and [Table 2-5](#) describes the LEDs.



Note

In Cisco IOS Release 12.2SR and later releases, the Supervisor Engine 2 is no longer supported on Cisco 7600 series routers.


Figure 2-6 *Supervisor Engine 2 Front Panel*

Table 2-4 Supervisor Engine 2 Front-Panel Controls

Component	Description
Status LEDs	Indicate the status of various functions on the module (see Table 2-5).
Reset Button	Restarts the router. Use a ballpoint pen tip or other small, pointed object to access the Reset button.
Console Port	Provides access to the router either locally (with a console terminal) or remotely (with a modem). The port is an EIA/TIA-232 asynchronous, serial connection with hardware flow control and an RJ-45 connector. See the “Connecting to the Console Port” section on page 3-9 for instructions on connecting to the console port.
Console Port Mode Switch	Enables you to connect a terminal to the console port using either the cable and adapters provided with the router (switch in the <i>in</i> position, factory default) or a Catalyst 5000 Supervisor Engine III console cable and adapter, not provided (switch in the <i>out</i> position).
PCMCIA Slot and LED	PCMCIA flash memory card slot. Do not remove the card from the slot while the disk LED is on. See the “Using Flash Memory Cards” section on page 3-12 for information about working with flash memory.
Switch Load Meter	A visual approximation of the current traffic load across the backplane.
Uplink Ports	Used to connect the router to another network device. Two dual-port Gigabit Ethernet uplink ports operate in full-duplex mode only. You can configure the ports with any combination of copper, short-wave (SX), long-wave/long-haul (LX/LH), extended-reach (ZX), and coarse wavelength division multiplexing (CWDM) 1000BASE-X Gigabit Interface Converters (GBICs). See the “Connecting to the Uplink Ports” section on page 3-10 for more information.

[Table 2-5](#) lists the LED functions on the Supervisor Engine 2.

Table 2-5 Supervisor Engine 2 LEDs

LED	Color	Description
STATUS	Green	All diagnostics pass; the module is operational (normal initialization sequence).
	Orange	The module is booting or running diagnostics (normal initialization sequence). An overtemperature condition has occurred. (A minor threshold has been exceeded during environmental monitoring.)
	Red	Diagnostic test failed; the module is not operational. (The fault occurred during the initialization sequence.) An overtemperature condition has occurred. (A major threshold has been exceeded during environmental monitoring.)

Table 2-5 Supervisor Engine 2 LEDs (continued)

LED	Color	Description
SYSTEM¹	Green	All chassis environmental monitors are reporting OK.
	Orange	The power supply or power supply fan failed. Incompatible power supplies are installed. The redundant clock failed. One VTT ² module has failed or the VTT module temperature minor threshold has been exceeded. ³
	Red	Two VTT modules failed or the VTT module temperature major threshold has been exceeded. ³ The temperature of the supervisor engine major threshold has been exceeded.
CONSOLE	Green	The supervisor engine is operational and active.
	Orange	The supervisor engine is in standby mode.
PWR MGMT¹	Green	Sufficient power is available for all modules.
	Orange	Sufficient power is not available for all modules.
SWITCH LOAD	-	If the system is operational, the switch load meter indicates (as an approximate percentage) the current traffic load over the backplane.
PCMCIA	-	The PCMCIA LED is lit when no PCMCIA card is in the slot and goes off when you insert a card.
LINK	Green	The port is operational.
	Orange	The link has been disabled by software.
	Flashing orange	The link is bad and has been disabled due to a hardware failure.
	Off	No signal is detected.

1. The SYSTEM and PWR MGMT LED indications on a redundant supervisor engine are synchronized to the active engine.
2. VTT = voltage termination. The VTT module terminates signals on the system switching bus.
3. If no redundant supervisor engine is installed and there is a VTT module minor or major overtemperature condition, the system shuts down.



CHAPTER 3

Installing and Configuring Route Switch Processors and Supervisor Engines

This chapter describes how to install and configure a route switch processor or supervisor engine. It also provides instructions for connecting to the console and uplink ports on the module.

This chapter contains the following sections:

- [Preparing for Installation or Removal, page 3-1](#)
- [Determining Module Location, page 3-3](#)
- [Installing a Supervisor Engine or Route Switch Processor, page 3-4](#)
- [Removing a Supervisor Engine or Route Switch Processor, page 3-7](#)
- [Hot Swapping \(OIR\) Modules, page 3-8](#)
- [Connecting to the Console Port, page 3-9](#)
- [Connecting to the Uplink Ports, page 3-10](#)
- [Using Flash Memory Cards, page 3-12](#)
- [Power Management and Environmental Monitoring, page 3-14](#)
- [Determining Software Feature Support, page 3-14](#)
- [Configuring a Supervisor Engine or Route Switch Processor, page 3-14](#)

Preparing for Installation or Removal

Before you attempt to install a supervisor engine or route switch processor in the router, be sure to:

- Review the safety precautions and electrostatic discharge guidelines in the [“Safety Precautions for Module Installation and Removal”](#) section on page 3-2 and the [“Preventing Electrostatic Discharge Damage”](#) section on page 3-2.
- Make sure you have on hand the tools required for the installation. (See the [“Tools Required for Module Installation”](#) section on page 3-3.)
- Determine which chassis slot to install the module in. (See the [“Determining Module Location”](#) section on page 3-3.)
- Consider cabling for the console and uplink ports. (See [Appendix B, “Cable and Connector Specifications.”](#))

Safety Precautions for Module Installation and Removal

Be sure to observe the following warnings and safety precautions when you work on the router.



Warning

Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing. Statement 1034



Warning

Hazardous network voltages are present in WAN ports regardless of whether power to the unit is OFF or ON. To avoid electric shock, use caution when working near WAN ports. When detaching cables, detach the end away from the unit first. Statement 1026



Warning

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. Statement 1051



Warning

Blank faceplates and cover panels serve three important functions: they prevent exposure to hazardous voltages and currents inside the chassis; they contain electromagnetic interference (EMI) that might disrupt other equipment; and they direct the flow of cooling air through the chassis. Do not operate the system unless all cards, faceplates, front covers, and rear covers are in place.

Statement 1029

Preventing Electrostatic Discharge Damage

Electrostatic discharge (ESD) damage, which can occur when electronic cards or components are improperly handled, results in complete or intermittent failures. The supervisor engine or route switch processor consists of printed circuit boards that are fixed in metal carriers. Electromagnetic interference (EMI) shielding and connectors are integral components of the carrier. Although the metal carrier helps to protect the boards from ESD, use a preventive antistatic strap during handling.

To prevent ESD damage, follow these guidelines whenever you handle supervisor engine or RSP modules and router components:

- Always use an ESD wrist or ankle strap and ensure that it makes good skin contact.
- Connect the equipment end of the strap to an unfinished chassis surface.
- When installing a component, use any available ejector levers or captive installation screws to properly seat the bus connectors in the backplane or midplane. These devices prevent accidental removal, provide proper grounding for the system, and help to ensure that bus connectors are properly seated.
- When removing a component, use any available ejector levers or captive installation screws to release the bus connectors from the backplane or midplane.
- Handle components by their handles or edges only; do not touch the printed circuit boards or connectors.
- Place a removed component board-side-up on an antistatic surface or in a static-shielding container. If you plan to return the component to the factory, immediately place it in a static-shielding container.

- Avoid contact between the printed circuit boards and clothing. The wrist strap only protects components from ESD voltages on the body; ESD voltages on clothing can still cause damage.
- Never attempt to remove the printed circuit board from the metal carrier.

**Caution**

Periodically check the resistance value of the antistatic strap. The measurement should be within the range of 1 and 10 megohms (Mohms).

Tools Required for Module Installation

These tools are required to install modules in the Cisco 7600 series router:

- Flat-blade screwdriver
- Antistatic wrist strap or other grounding device
- Antistatic mat or antistatic foam

Determining Module Location

Determine which chassis slot to install the module in. [Table 3-1](#) lists the chassis slots in which you can install a supervisor engine or route switch processor.

Table 3-1 Supervisor Engine and Route Switch Processor Slot Assignments

Module	Slot Assignments
Route Switch Processor 720 (RSP720-10GE)	<ul style="list-style-type: none"> • Slots 1 and 2 (3-slot enhanced [-S] chassis and 4-slot chassis) • Slots 5 and 6 (6-slot and 9-slot enhanced [-S] chassis and 9-slot chassis) • Not supported in the 3-slot, 6-slot, or 13-slot chassis
Route Switch Processor 720 (RSP720)	<ul style="list-style-type: none"> • Slots 1 and 2 (4-slot chassis) • Slots 5 and 6 (6-slot and 9-slot chassis, including enhanced [-S] chassis) • Slots 7 and 8 (13-slot chassis) • Not supported in the 3-slot chassis
Supervisor Engine 720 (Sup720)	<ul style="list-style-type: none"> • Slots 1 and 2 (3-slot and 4-slot chassis) • Slots 5 and 6 (6-slot and 9-slot chassis) • Slots 7 and 8 (13-slot chassis)

Table 3-1 Supervisor Engine and Route Switch Processor Slot Assignments (continued)

Module	Slot Assignments
Supervisor Engine 32	<ul style="list-style-type: none"> • Slots 1 and 2 (4-slot chassis) • Slots 5 and 6 (6-slot and 9-slot chassis) • Slots 7 and 8 (13-slot chassis) • Not supported in the 3-slot chassis
Supervisor Engine 2	<ul style="list-style-type: none"> • Slots 1 and 2 (all chassis) • Not supported in the 4-slot chassis

Installing a Supervisor Engine or Route Switch Processor

To install a supervisor engine or route switch processor module in the router, perform the following steps:



Caution

To prevent ESD damage, handle modules by the carrier edges only.

Step 1

Choose a slot for the module (see [Table 3-1](#)). Make sure that there is enough clearance to accommodate any equipment that will be connected to the ports on the module. If possible, place modules between empty slots that contain only blank module filler plates.

- a. If a blank module filler plate is installed in the slot in which you plan to install the module, remove the plate by removing its two Phillips pan-head screws.
- b. If another module is installed in the slot, remove the module by following the procedure in the [“Removing a Supervisor Engine or Route Switch Processor”](#) section on page 3-7.

Step 2

Verify that the captive installation screws are tightened on all of the modules installed in the chassis. This step ensures that the EMI gaskets on all modules are fully compressed in order to maximize the opening space for the new or replacement module.




Note


If the captive installation screws are loose, the EMI gaskets on the installed modules will push adjacent modules toward the open slot, which reduces the opening size and makes it difficult to install the new module.

Step 3

Fully open both ejector levers on the new module. (See [Figure 3-1](#).)

Figure 3-1 Ejector Levers and Captive Installation Screws

- Step 4** Position the module in the slot. Make sure that you align the sides of the module with the guides on each side of the slot. (See [Figure 3-2](#).)


Figure 3-2 Positioning the Module in the Slot

- Step 5** Carefully slide the module into the slot until the EMI gasket on the module makes contact with the module in the adjacent slot and both ejector levers have closed to approximately 45 degrees with respect to the module faceplate. (See [Figure 3-3](#).)
- Step 6** Using the thumb and forefinger of each hand, grasp the two ejector levers and press down to create a small (0.040 inch [1 mm]) gap between the module EMI gasket and the adjacent module. (See [Figure 3-3](#).)

**Caution**

Do not press down too forcefully on the ejector levers. They will bend and be damaged.

Figure 3-3 Clearing the EMI Gasket



- Step 7** While pressing down, simultaneously close both ejector levers to fully seat the module in the backplane connector. The ejector levers are fully closed when they are flush with the module faceplate.

**Note**

Failure to fully seat the module in the backplane connector can result in error messages.

- Step 8** Tighten the two captive installation screws on the module.

**Note**

Make sure the ejector levers are fully closed before tightening the captive installation screws.

**Note**

Blank module filler plates (Cisco part number 800-00292-01) should be installed in any empty chassis slots to keep dust out of the chassis and to maintain consistent airflow through the chassis.

Removing a Supervisor Engine or Route Switch Processor

Before you remove a supervisor engine or route switch processor (RSP) from the router, you should first save the current configuration using the **write {host file | network | terminal}** command. This step saves time when bringing the module back online. You can recover the configuration by downloading it from the server to the nonvolatile memory of the supervisor engine or RSP.

If the module is running Cisco IOS software, save the current running configuration by entering the **copy running-config startup-config** command.



Warning

Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing. Statement 1034



Warning

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. Statement 1051

To remove a supervisor engine or RSP, perform these steps:

- Step 1** Disconnect any cables attached to ports on the module.
- Step 2** Verify that the captive installation screws on all of the modules in the chassis are tight. This step assures that the space created by the removed module is maintained.



Note

If the captive installation screws are loose, the EMI gaskets on the installed modules will push the modules toward the open slot, which reduces the opening size and makes it difficult to remove the module.

- Step 3** Loosen the two captive installation screws on the module you plan to remove from the chassis.
- Step 4** Place your thumbs on the ejector levers (see [Figure 3-1](#)) and simultaneously rotate the ejector levers outward to unseat the module from the backplane connector.
- Step 5** Grasp the front edge of the module and slide the module straight out of the slot. If the chassis has horizontal slots, place your hand under the module to support its weight as you slide it out from the slot. Do not touch the module circuitry.



Caution

To prevent ESD damage, handle modules by the carrier edges only.

- Step 6** Place the module on an antistatic mat or antistatic foam, or immediately reinstall the module in another slot.
- Step 7** Install blank module filler plates (Cisco part number 800-00292-01) in any empty slots to keep dust out of the chassis and to maintain consistent airflow through the chassis.



Warning

Blank faceplates and cover panels serve three important functions: they prevent exposure to hazardous voltages and currents inside the chassis; they contain electromagnetic interference (EMI) that might disrupt other equipment; and they direct the flow of cooling air through the chassis. Do not operate the system unless all cards, faceplates, front covers, and rear covers are in place.

Statement 1029

Hot Swapping (OIR) Modules

Cisco 7600 series routers provide a feature that allows you to remove and replace a redundant supervisor engine or route switch processor (and other redundant cards) without powering down the router. This feature, called hot swapping or online insertion and removal (OIR), allows you to remove and replace a redundant module without disrupting router operation.

When two redundant modules are installed in the router, only one of the modules is active at a time. The other one runs in standby mode, ready to take over processing if the active module fails.

When you remove or insert a redundant module while the router is powered on and running, the router does the following:

1. Determines if there is sufficient power for the module.
2. Scans the backplane for configuration changes.
3. Initializes the newly inserted module. In addition, the system notes any removed modules and places those modules in the administratively shutdown state.
4. Places any previously configured interfaces on the module back to the state they were in when they were removed. Any newly inserted interfaces are put in the administratively shutdown state, as if they were present (but unconfigured) at boot time. If you insert the same type of module into a slot, its ports are configured and brought online up to the port count of the original module.

The router runs diagnostic tests on any new interfaces and the test results indicate the following:

- If the tests pass, the router is operating normally.
- If the new module is faulty, the router resumes normal operation but leaves the new interfaces disabled.
- If the diagnostic tests fail, the router stops operating, which usually indicates that the new module has a problem in the bus and should be removed.

**Caution**

To avoid erroneous failure messages, note the current configuration of all interfaces before you remove or replace another module, and allow at least 15 seconds for the system to reinitialize after a module has been removed or replaced.

Removing and Replacing Memory

The multilayer switch feature card (MSFC4) on the RSP720 supports several configurable options for dynamic random-access memory (DRAM). The router uses this memory to store routing tables, protocols, and network accounting applications. The DRAM resides on four dual in-line memory modules (DIMMs), which you can remove and replace in order to upgrade the module with more memory or to replace failed memory.

**Note**


If you are replacing DRAM on an existing MSFC4, upload your current configuration file to a remote server before you remove the memory. Otherwise, you will have to re-enter all your current configuration information manually after you replace the memory.

Connecting to the Console Port

The console port allows you to access the router either locally (with a console terminal) or remotely (with a modem). The console port is located on the front panel of the route switch processor or supervisor engine (see [Figure 3-4](#)). This section provides information about how to connect to the console port on a route switch processor or supervisor engine.

You must connect to the router through the console port to configure the router for the first time. You can also connect to the console port to perform diagnostics and troubleshoot problems on the router. For console cabling specifications, see the “[Console Port Cabling Specifications and Pinouts](#)” section on [page B-6](#).

Figure 3-4 Console Port Connector



Note

The console port is an EIA/TIA-232 asynchronous, serial connection with hardware flow control and an RJ-45 connector.



Note

The accessories kit that is shipped with your Cisco 7600 series router contains the necessary cable and adapters to connect a terminal or modem to the console port. See the “[Console Port Signals and Pinouts](#)” section on [page B-7](#) for cable and adapter pinouts.

Connecting a Terminal

To connect a terminal to the console port, observe the following guidelines. For a Supervisor Engine 2 additional guidelines apply, as described below.

- Use the RJ-45-to-RJ-45 rollover cable and data terminal equipment (DTE) adapter (labeled “Terminal”) provided with the router. Use the appropriate DTE adapter (RJ-45-to-DB-25 or RJ-45-to-DB-9).
- Set up the terminal as follows:
 - 9600 baud
 - 8 data bits
 - No parity
 - 2 stop bits
- Make sure that the baud rate of the terminal matches the default baud rate (9600 baud) of the console port. Check the terminal documentation to determine the baud rate.

Supervisor Engine 2

In addition to the above configuration requirements, note that with a Supervisor Engine 2 you can use two types of console cables to connect a terminal to the console port. To accommodate either type of cable, set the console port mode switch (to the right of the console port) as follows:

- To use the RJ-45-to-RJ-45 rollover cable and DTE adapter (labeled “Terminal”) provided with the router, make sure that the console port mode switch is in the *in* position (factory default).
- To use a Catalyst 5000 Supervisor Engine III console cable and adapter (not provided), make sure that the console port mode switch is in the *out* position, and use the appropriate adapter for the terminal connection. See the “[Console Port Mode 2 Signaling and Pinouts \(Sup2 Only\)](#)” section on [page B-10](#) for a list of console port pinouts when the switch is in the *out* position.

**Note**

To access the console port mode switch, use a ballpoint pen tip or other small, pointed object.

Connecting a Modem

To connect a modem to the console port, observe the following guidelines:

- Use the RJ-45-to-RJ-45 rollover cable and the RJ-45-to-DB-25 data communications equipment (DCE) adapter (labeled “Modem”) provided with the router.
- On a Supervisor Engine 2, make sure that the console port mode switch is in the *in* position (factory default).

Connecting to the Uplink Ports

The supervisor engine and route switch processor have uplink ports that you use to connect the router to other network devices. You can configure the ports with small form-factor pluggable (SFP), XENPAK, X2, or Gigabit Interface Converter (GBIC) optics modules.

[Table 3-2](#) lists the different types of uplink ports on each module. SFP, XENPAK, and X2 optics modules have SC, LC, or MT-RJ connectors. GBIC modules (on the Supervisor Engine 2) have SC connectors.

**Warning**

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. Statement 1051

**Caution**

Do not remove the plugs from the optical bores on the fiber-optic cable or the module port or until you are ready to connect the cable. The plugs protect the optical bores and cable from contamination.

Table 3-2 **Route Switch Processor and Supervisor Engine Uplink Ports**

Module	Uplink Ports
Route Switch Processor 720	Two 10/100/1000 BASE-T Gigabit Ethernet uplink ports: <ul style="list-style-type: none"> Port 1 requires that a 1-Gbps SFP module be installed. Port 2 supports either a 1-Gbps SFP module or a 10/100/1000-Mbps RJ-45 connector.
RSP720-10GE	Three Gigabit Ethernet uplink ports (1 gigabit per second [Gbps]): <ul style="list-style-type: none"> Ports 1 and 2 require that a 1-Gbps SFP module be installed. Port 3 supports either a 10/100/1000-Mbps RJ-45 connector. <p>Note Use Category 5 Shielded Twisted Pair cable at port 3.</p> <p>Two 10 Gigabit Ethernet uplink ports (10 Gbps):</p> <ul style="list-style-type: none"> Ports 4 and 5 require that a 10-Gbps X2 optics module be installed.
Supervisor Engine 720	Two Gigabit Ethernet uplink ports: <ul style="list-style-type: none"> Port 1 requires that a 1-Gbps SFP module be installed. Port 2 supports either a 1-Gbps SFP module or a 10/100/1000-Mbps RJ-45 connector.
Supervisor Engine 32	<ul style="list-style-type: none"> The WS-SUP32-GE-3B provides one 10/100/1000-Mbps RJ-45 uplink port and eight Gigabit Ethernet uplink ports. The Gigabit Ethernet uplink ports require SFP modules to be installed into them. The WS-SUP32-10GE-3B provides one 10/100/1000-Mbps uplink port and two 10-Gigabit Ethernet uplink ports. The Gigabit Ethernet uplink ports require XENPAK optics modules to be installed into them. The ports operate at 10 Gbps.
Supervisor Engine 2	<ul style="list-style-type: none"> Two dual-port Gigabit Ethernet ports operate in full-duplex mode only. You can configure the ports with any combination of copper, short-wave (SX), long-wave/long-haul (LX/LH), extended-reach (ZX), and coarse wavelength-division multiplexing (CWDM) 1000BASE-X GBICs.

To connect to the module uplink ports, follow these steps:

Step 1 If necessary, install an optics modules in the empty slots on the front panel.



Note The Sup720 and RSP720 provide two connectors for port 2; however, you can use only one of the connectors at a time. (Note that the RSP720-10GE provides only one port 2 connector.)

Step 2 Remove the plugs from the uplink ports and store them for future use.

Step 3 Remove the plugs from the connector on the fiber-optic cable.

Step 4 Insert the cable connector into the uplink port and make sure that both the transmit (Tx) and receive (Rx) fiber-optic cables are fully inserted into the connector.

Step 5 (Sup2 only) If you are using the LX/LH GBIC with multimode fiber (MMF), you need to install a patch cord between the GBIC and the MMF cable. For instructions, see the [“Patch Cord” section on page B-16](#).

**Note**

- If two RSPs or supervisor engines are installed, the uplink ports on the redundant (standby) module are active and can be used for normal traffic like any other ports in the chassis.
- In Cisco IOS Release 12.2SRC, the uplink ports on a standby RSP720-10GE are not active and cannot be used for normal traffic.

Using Flash Memory Cards

The front panel on the supervisor engine or route switch processor has one or two disk slots for flash memory cards. You can insert a Flash PC, CompactFlash, or MicroDrive memory card in the slot and use the card to store and run software images and configuration files or to serve as an I/O device.


See [Table 3-3](#) for memory options.

- The Route Switch Processor 720 with 10-GE uplink ports (RSP720-10GE) has a single disk slot (labeled DISK 0) that accepts CompactFlash cards.
- The Route Switch Processor 720 and Supervisor Engine 720 have two disk slots:
 - DISK 0 accepts a CompactFlash card only.
 - DISK 1 accepts either a CompactFlash card or a 1-GB MicroDrive.
- The Supervisor Engine 32 has a single slot (labeled DISK 0) that accepts CompactFlash cards and IBM MicroDrive cards.
- The Supervisor Engine 2 has a single slot (labeled PCMCIA) that accepts PCMCIA cards.

**Note**

You can insert and remove a flash memory card with the power on. Before you install a card, verify that the card is set with write protection off. The write-protection switch is located on the front edge of the card (when the printing is right side up and the edge connector end is away from you). (See [Figure 3-5](#).)

Figure 3-5 Locating the Flash PC Card Write-Protection Switch

**Note**

Not all flash memory cards have a write-protection switch.

Table 3-3 lists the Cisco product numbers of memory cards supported on Cisco 7600 supervisor engines and route switch processors.

Table 3-3 CompactFlash Memory Cards

Product Number	Description
RSP720 and RSP720-10GE Flash Memory Cards	
MEM-RSP720-CF256M	Cisco CompactFlash Memory Card, 256 MB
MEM-RSP720-CF512M	Cisco CompactFlash Memory Card, 512 MB
MEM-RSP720-CF1G	Cisco CompactFlash Memory Card, 1 GB
Sup720 and Sup32 Flash Memory Cards	
MEM-C6K-CPTFL64M	Cisco CompactFlash Memory Card, 64 MB
MEM-C6K-CPTFL128M	Cisco CompactFlash Memory Card, 128 MB
MEM-C6K-CPTFL256M	Cisco CompactFlash Memory Card, 256 MB
MEM-C6K-CPTFL512M	Cisco CompactFlash Memory Card, 512 MB
Sup2 Flash Memory Cards	
MEM-C6K-ATA-1-64M	Cisco ATA Type 1 Flash Memory Card, 64 MB

Installing a Flash Memory Card

To install a flash memory card, follow these steps:

- Step 1** Hold the memory card with the connector end of the card toward the slot. The connector end of the card is opposite the end with the write-protection switch (if there is one), which is shown in [Figure 3-5](#).
- Step 2** Slide the card into the slot until the device completely seats in the connector at the back of the slot and the ejector button pops out toward you.



Caution

Do not attempt to force the memory card fully into the slot or you could damage the connector pins. When correctly inserted, a portion of the device remains outside the slot.

- Step 3** Format the memory card the first time that it is installed in the system.



Note

Be sure to format the memory card with the type of supervisor engine or route switch processor that the card is being used with. A memory card formatted for one type of supervisor engine or route switch processor may not work with another type.

Removing a Flash Memory Card


Caution

Do not remove a flash memory card while its LED light is on or the file may become corrupted.

To remove a flash memory card, follow these steps:

-
- Step 1** Make sure that the Disk LED is off (no operations are in progress).
 - Step 2** Press the ejector button to disconnect the memory card from the connector at the back of the slot.
 - Step 3** Remove the memory card from the slot and place it in an antistatic bag.
-

Power Management and Environmental Monitoring

For detailed information on power management and environmental monitoring, see the *Cisco 7600 Series Router Cisco IOS Software Configuration Guide*.

Determining Software Feature Support

This section describes the Feature Navigator and Software Advisor tools. You can use these tools to determine which features are supported on the router and the minimum Cisco IOS software requirements for the hardware installed on your router.


Note

You must have an account on Cisco.com to access the Feature Navigator or Software Advisor tool.

- To determine which software features are supported by your route switch processor or supervisor engine, use the Feature Navigator tool at the following URL:

<http://tools.cisco.com/ITDIT/CFN/jsp/index.jsp>

- To check the minimum Cisco IOS software requirements for the hardware installed on your router, use the Software Advisor tool at the following URL:

<http://www.cisco.com/public/support/tac/tools.shtml>

This tool does not verify whether the line cards in a system are compatible, but it does provide the minimum Cisco IOS requirements for individual line cards, modules, or options.

Configuring a Supervisor Engine or Route Switch Processor

See the *Cisco 7600 Series Router Cisco IOS Software Configuration Guide* for information about how to configure the supervisor engine or route switch processor for operation.



APPENDIX A

Technical Specifications

This appendix provides the technical specifications for the Cisco 7600 route switch processors and supervisor engines.

Module Specifications

[Table A-1](#) lists the environmental and physical specifications for the Cisco 7600 route switch processors (RSPs) and supervisor engines.

Table A-1 *Environmental and Physical Specifications*

Item	Specification
Environmental	
Temperature, ambient operating	32 to 104°F (0 to 40°C)
Temperature, ambient nonoperating and storage	–40 to 167°F (–40 to 75°C)
Humidity (RH), ambient (noncondensing) operating	10% to 90%
Altitude operating	–197 to 6500 ft (–60 to 2000 m)
Physical Characteristics	
Dimensions (H x W x D)	1.2 x 14.4 x 16 in. (3.0 x 35.6 x 40.6 cm)
Weight	3 to 10 lb (1.4 to 4.5 kg)

Regulatory Standards Compliance

For information about the regulatory standards that Cisco 7600 series routers comply with, see *Regulatory Compliance and Safety Information for the Cisco 7600 Series Routers*.



APPENDIX **B**

Cable and Connector Specifications

This appendix lists the cable and connector specifications for the Cisco 7600 route switch processors (RSPs) and supervisor engines. It contains the following information:

- [Limiting Connection Distances, page B-1](#)
- [Uplink Port Transceiver Modules, page B-2](#)
- [Console Port Cabling Specifications and Pinouts, page B-6](#)
- [RJ-45 Connector, page B-10](#)
- [Fiber-Optic Connectors, page B-12](#)
- [LX/LH GBIC and MMF Cable Considerations, page B-16](#)

Limiting Connection Distances

The length of your networks and the distances between connections depend on the type of signal, the signal speed, and the transmission media (the type of cabling used to transmit the signals). For example, fiber-optic cable has a greater channel capacity than twisted-pair cabling. The distance and rate limits in this appendix are the IEEE-recommended maximum speeds and distances for signaling. You can get good results with rates and distances greater than those described here, although you do so at your own risk. You need to be aware of the electrical problems that may arise and compensate for them.

Uplink Port Transceiver Modules

Transceiver modules that plug into the front panel of the supervisor engine or route switch processor provide the uplink ports for the router. Several types of transceiver modules are available: small form-factor pluggable (SFP) modules, X2 modules, XENPAK modules, and Gigabit Interface Converter (GBIC) modules.

Table B-1 lists the orderable part numbers for supported transceiver modules. In addition, the following tables provide information about the modules and their cabling specifications:

- Table B-2 and Table B-3 provide information about 1GE uplink ports.
- Table B-4 and Table B-5 provide information about 10GE uplink ports.
- Table B-6 provides information about 1GE GBIC modules.

Table B-1 Uplink Port Transceiver Modules

Supervisor Engine or RSP	Transceiver Module Part Numbers
RSP720 and RSP720-10GE	10GE Uplink Ports (RSP720-10GE only):
	X2-10GB-SR
	X2-10GB-LR
	X2-10GB-ER
	X2-10GB-LX4
	X2-10GB-CX4
	1GE Uplink Ports:
	GLC-SX-MM
	GLC-LH-SM
	GLC-ZX-SM
	GLC-T
	GLC-BX-D
	GLC-BX-U
	SFP-GE-S
	SFP-GE-L
	SFP-GE-T
Supervisor Engine 720	GLC-SX-MM
	GLC-LH-SM
	GLC-ZX-SM
	GLC-T

Table B-1 Uplink Port Transceiver Modules (continued)

Supervisor Engine or RSP	Transceiver Module Part Numbers
Supervisor Engine 32	10GE Uplink Ports (WS-SUP32-10GE-3B only): XENPAK-10GB-CX4 XENPAK-10GB-SR XENPAK-10GB-LX4 XENPAK-10GB-LR XENPAK-10GB-ER 1GE Uplink Ports (WS-SUP32-GE-3B): GLC-SX-MM GLC-LH-SM GLC-ZX-SM GLC-T
Supervisor Engine 2	1000BASE-X GBIC modules, which are preinstalled

1GE Uplink Ports and Cabling Specifications

Table B-2 describes the 1GE SFP transceiver modules that are used for Cisco 7600 uplink ports. Table B-3 provides cabling specifications.


Note

Use Category 5 Shielded Twisted Pair cable at the port that supports the 10/100/1000-Mbps RJ-45 connector for the RSP720-10GE.

Table B-2 1GE SFP Transceiver Modules

Product ID	Description
Copper Modules	
GLC-SX-MM	1000BASE-SX SFP transceiver module for multimode fiber (MMF), 850-nm wavelength, LC connector
GLC-LH-SM	1000BASE-LX/LH SFP transceiver module for MMF and single-mode fiber (SMF), 1300-nm wavelength, LC connector
GLC-ZX-SM	1000BASE-ZX SFP transceiver module for SMF, 1550-nm wavelength, LC connector
GLC-T	1000BASE-T SFP transceiver module for Category 5, 5e, or 6 copper wire; 10/100/1000-Mbps RJ-45 connector
GLC-BX-D	1000BASE-BX10 SFP module for single-strand SMF, 1490-nm TX/1310-nm RX wavelength (downstream use in bidirectional single fiber applications), with Digital Optical Monitoring (DOM), LC connector
GLC-BX-U	1000BASE-BX10 SFP module for single-strand SMF, 1310-nm TX/1490-nm RX wavelength (upstream use in bidirectional single fiber applications), with DOM, LC connector
Fiber Modules	

Table B-2 1GE SFP Transceiver Modules (continued)

Product ID	Description
SFP-GE-S	1000BASE-SX SFP transceiver module for MMF, 850-nm wavelength, extended operating temperature range and DOM support, LC connector
SFP-GE-L	1000BASE-LX/LH SFP transceiver module for MMF and SMF, 1300-nm wavelength, extended operating temperature range and DOM support, LC connector
SFP-GE-T	1000BASE-T SFP transceiver module for Category 5, 5e, or 6 copper wire, extended operating temperature range and DOM support (NEBS 3ESD); 10/100/1000-Mbps RJ-45 connector

Table B-3 lists the cabling specifications for the 1GE uplink ports, which are located on SFP transceiver modules that plug into the front panel.

Table B-3 1GE Cabling Specifications

SFP Module (Product ID)	Wavelength (nm)	Fiber Type (MHz km)	Core Size (micron)	Modal Bandwidth (MHz km)	Maximum Cable Distance
GLC-SX-MM SFP-GE-S	850	MMF ¹	62.5 62.5 50 50	160 200 400 500	722 ft (220 m) 902 ft (275 m) 1640 ft (500 m) 1804 ft (550 m)
GLC-LH-SM SFP-GE-L	1300	MMF ²	62.5 50 50	500 400 500	1804 ft (550 m) 1804 ft (550 m) 1804 ft (550 m)
		SMF ³	9/10	—	6.2 mi (10 km)
GLC-ZX-SM	1550	SMF	9/10	—	43.5 mi (70 km)
		SMF ⁴	8	—	62.1 mi (100 km)
GLC-T SFP-GE-T	—	Cat 5, 5e, or 6 copper wire	—	—	328 ft (100 m)
GLC-BX-D	1490-nm TX 1310-nm RX	SMF ³	—	—	6.21 mi (10 km)
GLC-BX-U	1310-nm TX 1490-nm RX	SMF ³	—	—	6.21 mi (10 km)

- Multimode fiber (MMF) only.
- A mode-conditioning patch cord is required when using the GLC-LH-SM module with 62.5-micron diameter MMF for link distances greater than 984 ft (300 m). In addition, we do not recommend using the GLC-LH-SM module and MMF without a patch cord for very short link distances (tens of meters) because it may result in an elevated bit error rate (BER).

Install the patch cord between the module and the MMF cable on both the transmit and receive ends of the link. For more information about the patch cord, see the “Mode-Conditioning Patch Cord Description” section of the document at the following URL:

http://www.cisco.com/en/US/products/hw/routers/ps341/prod_module_installation_guide09186a00801cc731.html#wp29618

- ITU-T G.652 SMF as specified by the IEEE 802.3z standard.
- Dispersion-shifted single-mode fiber-optic cable.

10GE Uplink Ports and Cabling Specifications

Table B-4 describes the X2 and XENPAK transceiver modules used for the 10GE uplink ports on the RSP720-10GE and WS-SUP32-10GE-3B. Table B-5 provides cabling specifications.

Table B-4 10GE X2 and XENPAK Transceiver Modules

Product ID	Description
X2-10GB-SR XENPAK-10GB-SR	10GBASE-SR X2 or XENPAK transceiver module for MMF, 850-nm wavelength, SC duplex connector
X2-10GB-LR XENPAK-10GB-LR	10GBASE-LR X2 or XENPAK transceiver module for SMF, 1310-nm wavelength, SC duplex connector
X2-10GB-ER XENPAK-10GB-ER	10GBASE-ER X2 or XENPAK transceiver module for SMF, 1550-nm wavelength, SC duplex connector
X2-10GB-LX4 XENPAK-10GB-LX4	10GBASE-LX4 X2 or XENPAK transceiver module for MMF, 1310-nm wavelength, SC duplex connector
X2-10GB-CX4 XENPAK-10GB-CX4	10GBASE-CX4 X2 or XENPAK transceiver module for CX4 copper cable, Infiniband 4X connector

Table B-5 lists the cabling specifications for 10GE uplink ports, which are located on X2 or XENPAK transceiver modules that plug into the RSP720-10GE and WS-SUP32-10GE-3B front panel.



Note

The 10GE uplink ports on the RSP720-10GE support X2 transceiver modules only.

Table B-5 10GE Cabling Specifications

X2 Device (Product ID)	Wavelength (nm)	Fiber Type (MHz km)	Core Size (micron)	Modal Bandwidth (MHz km)	Cable Distance ¹
X2-10GB-SR XENPAK-10GB-SR	850	MMF	62.5 62.5 50 50 50	160 200 400 500 2000	85.3 ft (26 m) 108.3 ft (33 m) 216.5 ft (66 m) 269.0 ft (82 m) 984.3 ft (300 m)
X2-10GB-LR XENPAK-10GB-LR	1310	SMF	ITU-T G.652	—	6.2 mi (10 km)
X2-10GB-ER ² XENPAK-10GB-ER	1550	SMF	ITU-T G.652	—	24.9 mi (40 km) ³
X2-10GB-LX4 XENPAK-10GB-LX4	1310	MMF	62.5 50 50	500 400 500	984.3 ft (300 m) 787.4 ft (240 m) 984.3 ft (300 m)
X2-10GB-CX4 XENPAK-10GB-CX4	—	CX4 (copper)	—	—	49.2 ft (15 m)

1. Minimum cabling distance for -LR, -SR, -LX4, and -ER modules is 2 m, according to the IEEE 802.3ae standard.

- Requires 5 dB 1550 nm fixed loss attenuator for < 20 km. Attenuator is available as a spare. The part number is WS-X6K-5DB-ATT=.
- Links longer than 30 km are considered engineered links.

GBIC Module Cabling Specifications

Table B-6 provides cabling specifications for the 1000BASE-X interfaces on the Gigabit Interface Converter (GBIC) modules installed in the Supervisor Engine 2. All GBIC interfaces have SC connectors, and the minimum cable distance for all GBICs listed (MMF and SMF) is 6.5 feet (2 meters).

Table B-6 Gigabit Ethernet Maximum Transmission Distances

GBIC	Wavelength (nm)	Fiber Type (MHz km)	Core Size ¹ (micron)	Modal Bandwidth (MHz km)	Cable Distance ²
SX ³	850	MMF	62	160	722 ft (220 m)
			62	200	902 ft (275 m)
			50	400	1640 ft (500 m)
			50	500	1804 ft (550 m)
LX/LH	1300	MMF ⁴	62	500	1804 ft (550 m)
			50	400	1804 ft (550 m)
			50	500	1804 ft (550 m)
		SMF (LX/LH)	9/10	—	6.2 mi (10 km)
ZX ⁵	1550	SMF ⁶	9/10	—	43.5 mi (70 km) ⁷
			8	—	62.1 mi (100 km)

- Core size refers to the core diameter. The cladding diameter is usually 25 microns.
- Cable distances are based on fiber loss.
- MMF only.
- Patch cord required.
- A maximum of 24 1000BASE-ZX GBICs is allowed for each system to comply with FCC Class A regulations.
- Dispersion-shifted single-mode fiber-optic cable.
- The minimum link distance for ZX GBICs is 6.2 miles (10 km) with an 8-dB attenuator installed at each end of the link. Without attenuators, the minimum link distance is 24.9 miles (40 km).

Console Port Cabling Specifications and Pinouts

The console port, which is located on the front panel of the supervisor engine or route switch processor, provides access to the Cisco 7600 router. The following sections provide information about the console port cabling specifications and the port's signals and pinouts.

- [Console Port Cabling Specifications, page B-6](#)
- [Console Port Signals and Pinouts, page B-7](#)
- [Console Port Mode 2 Signaling and Pinouts \(Sup2 Only\), page B-10](#)

Console Port Cabling Specifications

Table B-7 lists the maximum transmission distances for console port cables. See the “[Console Port Signals and Pinouts](#)” section on page B-7 for console port and cable pinout information.

The accessories kit that is shipped with your router contains the necessary cable and adapters to connect a terminal or modem to the front-panel console port.

Table B-7 EIA/TIA-232 Transmission Speed Versus Distance

Rate (bps)	Distance (feet)	Distance (meters)
2400	200	60
4800	100	30
9600	50	15
19,200	25	7.6
38,400	12	3.7
56,000	8.6	2.6

Console Port Signals and Pinouts


The Cisco 7600 series router is shipped with an accessories kit that contains the cable and adapters you need to connect a console (an ASCII terminal or PC running terminal emulation software) or modem to the console port on the front panel of the supervisor engine or route switch processor. For information about the signals and pinouts for the Supervisor Engine 2 console port in mode 2, see the [“Console Port Mode 2 Signaling and Pinouts \(Sup2 Only\)”](#) section on page B-10.

The accessories kit includes these items:

- RJ-45-to-RJ-45 rollover cable
- RJ-45-to-DB-9 female DTE adapter (labeled “Terminal”)
- RJ-45-to-DB-25 female DTE adapter (labeled “Terminal”)
- RJ-45-to-DB-25 male DCE adapter (labeled “Modem”)

Identifying a Rollover Cable

You can identify a rollover cable by comparing the two ends of the cable. Holding the cables side-by-side, with the tab at the back, the wire connected to the pin on the outside of the left plug should be the same color as the wire connected to the pin on the outside of the right plug. (See [Figure B-1](#).) If you purchased your cable from Cisco Systems, pin 1 is white on one connector, and pin 8 is white on the other (a rollover cable reverses pins 1 and 8, 2 and 7, 3 and 6, and 4 and 5).

Figure B-1 Identifying a Rollover Cable

DB-9 Adapter (for Connecting to a PC)

Use the RJ-45-to-RJ-45 rollover cable and RJ-45-to-DB-9 female DTE adapter (labeled “Terminal”) to connect the console port to a PC running terminal emulation software. [Table B-8](#) lists the pinouts for the asynchronous serial console port, the RJ-45-to-RJ-45 rollover cable, and the RJ-45-to-DB-9 female DTE adapter.

Table B-8 Console Port DB-9 Adapter Pinouts

Console Port	RJ-45-to-RJ-45 Rollover Cable		RJ-45-to-DB-9 Terminal Adapter	Console Device
	RJ-45 Pin	RJ-45 Pin	DB-9 Pin	Signal
RTS	1 ¹	8	8	CTS
DTR	2	7	6	DSR
TxD	3	6	2	RxD
GND	4	5	5	GND
GND	5	4	5	GND
RxD	6	3	3	TxD
DSR	7	2	4	DTR
CTS	8 ¹	1	7	RTS

1. Pin 1 is connected internally to Pin 8.

DB-25 Adapter (for Connecting to a Terminal)

Use the RJ-45-to-RJ-45 rollover cable and RJ-45-to-DB-25 female DTE adapter (labeled “Terminal”) to connect the console port to a terminal. [Table B-9](#) lists the pinouts for the asynchronous serial console port, the RJ-45-to-RJ-45 rollover cable, and the RJ-45-to-DB-25 female DTE adapter.

Table B-9 Console Port DB-25 Adapter Pinouts

Console Port	RJ-45-to-RJ-45 Rollover Cable		RJ-45-to-DB-25 Terminal Adapter	Console Device
Signal	RJ-45 Pin	RJ-45 Pin	DB-25 Pin	Signal
RTS	1 ¹	8	5	CTS
DTR	2	7	6	DSR
TxD	3	6	3	RxD
GND	4	5	7	GND
GND	5	4	7	GND
RxD	6	3	2	TxD
DSR	7	2	20	DTR
CTS	8 ¹	1	4	RTS

1. Pin 1 is connected internally to Pin 8.

Modem Adapter

Use the RJ-45-to-RJ-45 rollover cable and RJ-45-to-DB-25 male DCE adapter (labeled “Modem”) to connect the console port to a modem. [Table B-10](#) lists the pinouts for the asynchronous serial console port, the RJ-45-to-RJ-45 rollover cable, and the RJ-45-to-DB-25 male DCE adapter.

Table B-10 Console Port Modem Adapter Pinouts

Console Port	RJ-45-to-RJ-45 Rollover Cable		RJ-45-to-DB-25 Modem Adapter	Modem
Signal	RJ-45 Pin	RJ-45 Pin	DB-25 Pin	Signal
RTS	1 ¹	8	4	RTS
DTR	2	7	20	DTR
TxD	3	6	3	TxD
GND	4	5	7	GND
GND	5	4	7	GND
RxD	6	3	2	RxD
DSR	7	2	8	DCD
CTS	8 ¹	1	5	CTS

1. Pin 1 is connected internally to Pin 8.

Console Port Mode 2 Signaling and Pinouts (Sup2 Only)

Table B-11 lists the pinouts for the Supervisor Engine 2 console port mode switch in mode 2 (switch in the *out* position). In this mode, you can connect a terminal to the supervisor engine using a Catalyst 5000 family Supervisor Engine III console cable and adapter (not provided). For instructions, see “Supervisor Engine 2” in the “Connecting a Terminal” section on page 3-9.

Table B-11 Console Port Pinouts (Supervisor Engine 2, Port Mode Switch Out)

Console Port	Console Device
Pin (Signal Name)	Input/Output
1 (RTS) ¹	Output
2 (DTR)	Output
3 (RxD)	Input
4 (GND)	GND
5 (GND)	GND
6 (TxD)	Output
7 (DSR)	Input
8 (CTS) ¹	Input

1. Pin 1 is connected internally to Pin 8.

RJ-45 Connector

The RJ-45 connector is used to connect a Category 3, Category 5, Category 5e, or Category 6 FTP from the external network to the module interface connector. (See Figure B-2.) Table B-12 lists the connector pinouts and signal names for a 10/100BASE-T crossover (MDI-X) cable. Figure B-3 shows a schematic of the 10/100BASE-T crossover cable. Table B-13 lists the connector pinouts and signal names for a 1000BASE-T crossover (MDI-X) cable. Figure B-4 shows a schematic of the 1000BASE-T crossover cable.



Caution


Category 5e and Category 6 cables can store high levels of static electricity because of the dielectric properties of the materials used in their construction. Always ground the cables (especially in new cable runs) to a suitable and safe earth ground before connecting them to the module.



Caution

To comply with Telcordia GR-1089 intrabuilding, lightning-immunity requirements, you must use foil-twisted pair (FTP) cable that is properly grounded at both ends.

Inline power for IP phones uses connector pins 1, 2, 3, and 6 in a Category 5, Category 5e, or Category 6 cable to transmit power (6.3 W) from the router. This method of supplying power is sometimes called *phantom power* because the IP phone power travels over the same pairs of wires used to transmit the Ethernet signals. The IP phone voltage is completely transparent to the Ethernet signals and does not interfere with their operation.

Figure B-2 *RJ-45 Interface Cable Connector***Table B-12** *10/100BASE-T Crossover Cable Pinout (MDI-X)*

Side 1 Pin (Signal)	Side 2 Pin (Signal)
1 (RD+)	3 (TD+)
2 (RD-)	6 (TD-)
3 (TD+)	1 (RD+)
6 (TD-)	2 (RD-)
4 (Not used)	4 (Not used)
5 (Not used)	5 (Not used)
7 (Not used)	7 (Not used)
8 (Not used)	8 (Not used)



Figure B-3 *Twisted-Pair Crossover 10/100BASE-T Cable Schematic*

Table B-13 1000BASE-T Crossover Cable Pinout (MDI-X)

Side 1 Pin (Signal)	Side 2 Pin (Signal)
1 (TP0+)	3 (TP1+)
2 (TP0-)	6 (TP1-)
3 (TP1+)	1 (TP0+)
6 (TP1-)	2 (TP1-)
4 (TP2+)	7 (TP3+)
5 (TP2-)	8 (TP3-)
7 (TP3+)	4 (TP2+)
8 (TP3-)	5 (TP2-)

Figure B-4 Twisted-Pair Crossover 1000BASE-T Cable Schematic

Fiber-Optic Connectors

This section describes the SC, MT-RJ, and LC fiber-optic connectors and provides instructions for cleaning the fiber-optics connectors. It contains the following sections:

- [SC Connectors, page B-12](#)
- [MT-RJ Connectors, page B-13](#)
- [LC Connectors, page B-14](#)
- [Cleaning the Fiber-Optic Connectors, page B-15](#)


SC Connectors



Warning

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. Statement 1051

The SC single-mode fiber connector is used to connect fiber-optic module ports with the external network. (See [Figure B-5](#).)

Figure B-5 SC Optical Connector

Always make sure that you insert the connector completely into the socket. This action is especially important when you are making a connection between a module and a long distance (1.24 miles [2 kilometers]) or a suspected highly attenuated network. If the LINK LED on the supervisor engine or route switch processor does not light, try removing the network cable plug and reinserting it firmly into the module socket. It is possible that enough dirt or skin oils have accumulated on the plug faceplate (around the optical-fiber openings) to generate significant attenuation, reducing the optical power levels below threshold levels so that a link cannot be made.

**Caution**

Use extreme care when removing or installing connectors so that you do not damage the connector housing or scratch the end-face surface of the fiber. Always install protective covers on unused or disconnected components to prevent contamination. Always clean fiber connectors before installing them.


For fiber-optic connector cleaning instructions, see the [“Cleaning the Fiber-Optic Connectors”](#) section on page B-15.

MT-RJ Connectors

**Warning**

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. Statement 1051

The MT-RJ style connector is used on fiber-optic modules to increase port density. (See [Figure B-6](#).)

Figure B-6 MT-RJ Optical Connector

When you are connecting MT-RJ cables to a module, make sure you firmly press the connector plug into the socket. The upper edge of the plug must snap into the upper front edge of the socket. You may or may not hear an audible click. Gently pull on the plug to confirm whether or not the plug is locked into the socket. To disconnect the plug from the socket, press down on the raised portion on top of the plug (releasing the latch). You should hear an audible click indicating that the latch has released. Carefully pull the plug out of the socket.

Make sure that you insert the connector completely into the socket. This action is especially important when you are making a connection between a module and a long distance (1.24 miles [2 kilometers]) or a suspected highly attenuated network. If the LINK LED on the supervisor engine or route switch processor does not light, try removing the network cable plug and reinserting it firmly into the module socket. It is possible that enough dirt or skin oils have accumulated on the plug faceplate (around the optical-fiber openings) to generate significant attenuation, reducing the optical power levels below threshold levels so that a link cannot be made.

**Caution**

Use extreme care when removing or installing connectors so that you do not damage the connector housing or scratch the end-face surface of the fiber. Always install protective covers on unused or disconnected components to prevent contamination. Always clean fiber connectors before installing them.


For fiber-optic connector cleaning instructions, see the [“Cleaning the Fiber-Optic Connectors” section on page B-15](#).

When you disconnect the fiber-optic cable from the module, grip the body of the connector. Do not grip the connector jacket-sleeve. Gripping the sleeve can, over time, compromise the integrity of the fiber-optic cable termination in the MT-RJ connector.

LC Connectors

The small form-factor pluggable (SFP) transceiver modules used on the Supervisor Engine 720, Route Switch Processor 720, and RSP720-10GE uplink ports use either MT-RJ connectors or LC connectors depending on the SFP module vendor. [Figure B-7](#) shows an LC connector.

Figure B-7 LC Fiber-Optic Connector

**Caution**

Use extreme care when removing or installing connectors so that you do not damage the connector housing or scratch the end-face surface of the fiber. Always install protective covers on unused or disconnected components to prevent contamination. Always clean fiber connectors before installing them.

For fiber-optic connector cleaning instructions, see the [“Cleaning the Fiber-Optic Connectors” section on page B-15](#).

When you disconnect the fiber-optic cable from the module, grip the body of the connector. Do not grip the connector jacket-sleeve. Gripping the sleeve can, over time, compromise the integrity of the fiber-optic cable termination in the LC connector.

Cleaning the Fiber-Optic Connectors

Fiber-optic connectors are used to connect two fibers together. When these connectors are used in a communications system, proper connection is critical.

Fiber-optic connectors differ from electrical connectors or microwave connectors. In a fiber-optic system, light is transmitted through an extremely small fiber core. Because fiber cores are often 62.5 microns or less in diameter in multimode fiber (MMF) and 8.3 to 10 microns in single-mode fiber (SMF), dust particles and any contamination on the face of the fiber core can degrade the performance of the connector interface where the two cores meet. The connector must be precisely aligned, and the connector interface must be absolutely free of trapped contaminants.

**Caution**

Use extreme care when removing or installing connectors so that you do not damage the connector housing or scratch the end-face surface of the fiber. Always install protective covers on unused or disconnected components to prevent contamination. Always clean fiber connectors before installing them.

To clean the fiber-optic connectors, use a CLETOP cassette cleaner (type A for SC connectors or type B for MT-RJ connectors) and follow the product instructions. If a CLETOP cassette cleaner is not available, follow these steps:

- Step 1** Gently wipe the ferrules and end-face surfaces of the connector with an alcohol pad. Be sure that the pad makes full contact with the end-face surfaces. Wait five seconds for the surfaces to dry and repeat.
- Step 2** Blow dry the connectors with canned, dry, oil-free, compressed air.
- Step 3** Use a magnifying glass or inspection microscope to inspect the ferrule. If contaminants are visible, repeat the cleaning procedure.

The connectors used inside the system have been cleaned by the manufacturer and connected to the adapters in the proper manner. The operation of the system should be error-free if the customer provides clean connectors on the application side, follows the previous directions, and follows the listed guidelines:

- Clean the connectors using lens tissues before connecting to the adapters. Use pure alcohol to remove contamination.
- Do not clean the inside of the connector adapters.
- Do not use force or quick movements when connecting the fiber-optic connectors in the adapters.
- Cover the connector adapters to avoid contaminating the inside of the adapters while cleaning the chassis.
- Cover the connectors and adapters to prevent the inside of the adapters or the surface of the connectors from getting dirty when not using the connectors.

**Note**

If the surface of the fiber-optic connector is not clean or does not have an even shine, repeat the process using a fresh surface of the alcohol pad.

LX/LH GBIC and MMF Cable Considerations

The following sections describe the things you should consider if you are using a Supervisor Engine 2 with a long wavelength/long haul (LX/LH) GBIC with 62.5-micron diameter MMF cable.

Patch Cord

When using the long wavelength/long haul (LX/LH) GBIC with 62.5-micron diameter MMF on links that span more than 984 feet (300 meters), a mode-conditioning patch cord is required. You must install the patch cord (Cisco product number CAB-GELX-625 or equivalent) between the GBIC and the MMF cable on both the transmit and receive ends of the link.



Note

We also recommend using a patch cord between the LX/LH GBIC and MMF cable for very short link distances (10 to 100 meters). Without a patch cord, the link can have an elevated bit error rate (BER).




Note

The patch cord is required to comply with IEEE standards. The IEEE found that link distances could not be met with certain types of fiber-optic cable due to a problem in the center of some fiber-optic cable cores. The solution is to launch light from the laser at a precise offset from the center by using the mode-conditioning patch cord. At the output end of the patch cord, the LX/LH GBIC complies with the IEEE 802.3z standard for 1000BASE-LX.

Patch Cord Configuration Example

Figure B-8 shows a typical patch cord configuration.

Figure B-8 Patch Cord Configuration




Patch Cord Installation

**Warning**

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. Statement 1051

Plug the end of the patch cord labeled “To Equipment” into the GBIC (see [Figure B-9](#)). Plug the end labeled “To Cable Plant” into the patch panel. The patch cord is 9.84 feet (3 meters) long and has duplex SC male connectors at each end.

Figure B-9 Patch Cord Installation





INDEX

Symbols

3-13

A

accessories kit, console port 3-9, B-7

ACTIVE LED

Sup Eng 720, Sup Eng 32 2-14

adapters

DB-25 B-9

DB-9 B-8

modem B-9

addresses

MAC 1-6

physical interface 1-5

port 1-5

air flow, chassis 3-6, 3-7

B

blank module carriers 3-6, 3-7

bootflash 1-4

C

cabling

console port B-6

console ports B-7

Gigabit Ethernet limitations B-4, B-5, B-6

specifications B-1

category 5e static electricity caution B-10

category 6 static electricity caution B-10

Cisco 7600 series router

features 1-3

overview 1-1

commands

copy running-config 3-7

write 3-7

CompactFlash and MicroDrive support 3-13

CompactFlash cards

front-panel slot 2-13, 3-12

installing 3-13

removing 3-14

connecting

modem 3-10

terminal to supervisor engine or RSP 3-9

to console port 3-9

to console port (Sup2) 3-10

connectors

cleaning fiber optic B-15

LC B-14

MT-RJ B-13

RJ-45 B-11

SC B-12

CONSOLE LED, Sup2 2-16

console port

accessories kit 3-9

cable transmission distances B-6

connecting to 3-9

mode 2 signaling (Sup Eng 2) B-10

copy running-config command 3-7

D

DB-25 adapter [B-9](#)
 DB-9 adapter [B-8](#)
 DISK LED, Sup Eng 720, Sup Eng 32 [2-14](#)
 DRAM, default [1-4](#)

E

EEPROM [1-4, 1-6](#)
 EIA/TIA-232 transmission speeds [B-7](#)
 environmental monitoring [3-14](#)
 environmental specifications (table) [A-1](#)
 ESD, preventing damage [3-2](#)
 excessive link spans [B-16](#)

F

fault tolerance and redundancy [1-3](#)
 fiber optics
 cleaning [B-15](#)
 connectors [B-12](#)
 filler plate, module [3-6, 3-7](#)
 flash memory cards [3-12, 3-13, 3-14](#)
 front panel
 console port mode switch [3-10](#)
 disk slots [3-12](#)
 LEDs [2-13](#)
 Reset button [2-13](#)
 Sup2 (figure) [2-14](#)
 uplink ports [2-13](#)
 front panel controls [2-13](#)
 RSP720, Sup720, Sup32 [2-13](#)
 Sup2 [2-15](#)

G

GBICs, connecting to [3-10](#)
 Gigabit Ethernet cables [B-4, B-5, B-6](#)

H

hot swapping
 Cisco 7600 series router components [1-4](#)
 modules [3-8](#)
 supervisor engines and RSPs [3-8](#)

I

installing
 flash memory cards [3-13](#)
 modules [3-4](#)
 patch cord [B-17](#)
 interfaces, addresses of [1-5](#)

L

LC connectors [B-14](#)
 LEDs
 ACTIVE [2-14](#)
 CONSOLE [2-16](#)
 DISK (Sup Eng 720, Sup Eng 32 only) [2-14](#)
 front panel [2-13](#)
 LINK [2-14, 2-16](#)
 PCMCIA (Sup Eng 2 only) [2-16](#)
 PWR MGMT [2-14, 2-16](#)
 RSP720, Sup720, Sup32 [2-13](#)
 STATUS [2-13, 2-15](#)
 Sup2 [2-15](#)
 SWITCH LOAD (Sup Eng 2 only) [2-16](#)
 SYSTEM [2-13, 2-16](#)

LINK LEDSup Eng 2 [2-16](#)Sup Eng 720, Sup Eng 32 [2-14](#)link spans, excessive [B-16](#)LX/LH GBIC [B-16](#)

MMAC address [1-5, 1-6](#)managing the router [1-4](#)memory, default [1-4](#)memory components [1-4](#)modem, connecting to the supervisor engine or RSP [3-10](#)modem adapter [B-9](#)

modules

blank module carriers [3-6, 3-7](#)hot swapping [3-8](#)installing [3-4](#)removing from chassis [3-7](#)tools for installing [3-3](#)MT-RJ connectors [B-13](#)

NNVRAM [1-4](#)

Oonline insertion and removal (OIR) [3-8](#)

P

patch cord

configuration example [B-16](#)installation [B-17](#)using with LX/LH GBICs [B-16](#)

PCMCIA

See also Flash PC cardsPCMCIA flash file system [1-4](#)PCMCIA LED, Sup Eng 2 [2-16](#)PCMCIA slot, description [2-13, 3-12](#)physical interface addresses [1-5](#)physical specifications (table) [A-1](#)port addresses [1-5](#)port addresses (figure) [1-6](#)port mode switch, console port [3-10](#)port numbers [1-5, 1-6](#)power management [3-14](#)preventing ESD damage [3-2](#)

PWR MGMT LED

Sup Eng 2 [2-16](#)Sup Eng 720, Sup Eng 32 [2-14](#)

QQoS, RSP720-10GE [2-10](#)

Rredundancy [1-3](#)

removing

flash memory cards [3-14](#)modules [3-7](#)Reset button [2-13](#)RJ-45 connectors [B-10, B-11](#)rollover cable [B-7](#)router, managing [1-4](#)route switch processor [1-6](#)CompactFlash support [3-13](#)connecting to [3-9, 3-10](#)hot swapping (OIR) [3-8](#)installing [3-4](#)removing [3-7](#)tools for installing and removing [3-3](#)Route Switch Processor 720 (RSP720) [2-13](#)CompactFlash support [3-12](#)

front panel (figure) [2-7](#)

uplink ports [3-11](#)

Route Switch Processor 720 (RSP720-10GE)

CompactFlash support [3-12](#)

RSP720-10GE [2-8](#)

RSP720-10GE, QoS [2-11](#)

S

SC connector [B-12](#)

slot numbers [1-5](#)

specifications, cabling [B-1](#)

specifications, environmental and physical (table) [A-1](#)

STATUS LED

Sup Eng 2 [2-15](#)

Sup Eng 720, Sup Eng 32 [2-13](#)

supervisor engine

CompactFlash support [3-13](#)

configuration information [2-3](#)

connecting to [3-9, 3-10](#)

flash memory slot [2-13, 3-12](#)

hot swapping [3-8](#)

hot swapping (OIR) [3-8](#)

installing [3-4](#)

LEDs (tables) [2-15](#)

port numbers [1-6](#)

removing [3-7](#)

slot assignments (table) [3-3](#)

tools for installing and removing [3-3](#)

Supervisor Engine 2 (Sup2)

CompactFlash support [3-12](#)

connecting to console port [3-10](#)

front panel (figure) [2-14](#)

front panel controls [2-15](#)

LEDs (table) [2-15](#)

uplink ports [3-11](#)

Supervisor Engine 32 (Sup32)

CompactFlash support [3-12](#)

front panel (figure) [2-12](#)

front panel controls [2-13](#)

LEDs (table) [2-13](#)

uplink ports [3-11](#)

USB ports [2-13](#)

Supervisor Engine 720 (Sup720)

CompactFlash support [3-12](#)

front panel (figure) [2-12](#)

front panel controls [2-13](#)

LEDs (table) [2-13](#)

uplink ports [3-11](#)

SWITCH LOAD LED, Sup Eng 2 [2-16](#)

SYSTEM LED

Sup Eng 2 [2-16](#)

Sup Eng 720, Sup Eng 32 [2-13](#)

T

terminal, connecting to the supervisor engine or RSP [3-9](#)

tools required for installing cards [3-3](#)

U

uplink ports

connecting to [3-10](#)

description [2-13](#)

RSP720 [3-11](#)

Sup2 [3-11](#)

Sup32 [3-11](#)

Sup720 [3-11](#)

USB ports, Sup32 [2-13](#)

W

write command [3-7](#)

write-protection switch, flash memory card (figure) [3-12](#)